R-879_FC+INTRO EN.qxd 6/4/07 11:49 AM Page A

SHARP

Important

R-879
MICROWAVE OVEN WITH TOP & BOTTOM GRILL AND CONVECTION

OPERATION MANUAL WITH COOKBOOK

OPERATION MANUAL

This operation manual contains important information which you should read carefully before using your microwave oven.

IMPORTANT: There may be a serious risk to health if this operation manual is not followed or if the oven is modified so that it operates with the door open.

900 W (IEC 60705)

ENGLISH

R-879_FC+INTRO EN.qxd 6/4/07 11:49 AM Page B

Dear Customer,

Congratulations on acquiring your new combi-microwave oven with double grill and convection, which from now on will make your kitchen chores considerably easier.
You will be pleasantly surprised by the kinds of things you can do with your combined microwave oven. Not only can you use it for rapid defrosting or heating up of food, you can also prepare whole meals. The combination of microwave, convection and double grill means that food can cook and brown at the same time, and much faster, than by using the conventional method.
In our test kitchen our microwave team has gathered together a selection of the most delicious international recipes which are quick and simple to prepare.
Be inspired by the recipes we have included and prepare your own favourite dishes in your microwave oven.
There are so many advantages to having a microwave oven which we are sure you will find exciting:

- Food can be prepared directly in the serving dishes, leaving less to wash up.
- Shorter cooking times and the use of little water and fat ensure that many vitamins, minerals and characteristic flavours are preserved.

We advise you to read the cookery book guide and operating instructions carefully.
You will then easily understand how to use your oven.

Enjoy using your combined microwave oven and trying out the delicious recipes.

Your Microwave-Team

R-879_FC+INTRO EN.qxd 6/4/07 11:49 AM Page 1

GB

Attention:
Your product is marked with this symbol.
It means that used electrical and electronic products should not be mixed with general household waste. There is a separate collection system for these products.

A. Information on Disposal for Users (private households)

1. In the European Union

Attention: If you want to dispose of this equipment, please do not use the ordinary dust bin!

Used electrical and electronic equipment must be treated separately and in accordance with legislation that requires proper treatment, recovery and recycling of used electrical and electronic equipment.

Following the implementation by member states, private households within the EU states may return their used electrical and electronic equipment to designated collection facilities free of charge*.

In some countries* your local retailer may also take back your old product free of charge if you purchase a similar new one.

*) Please contact your local authority for further details.

If your used electrical or electronic equipment has batteries or accumulators, please dispose of these separately beforehand according to local requirements.

By disposing of this product correctly you will help ensure that the waste undergoes the necessary treatment, recovery and recycling and thus prevent potential negative effects on the environment and human health which could otherwise arise due to inappropriate waste handling.

2. In other Countries outside the EU

If you wish to discard this product, please contact your local authorities and ask for the correct method of disposal.

For Switzerland: Used electrical or electronic equipment can be returned free of charge to the dealer, even if you don't purchase a new product. Further collection facilities are listed on the homepage of www.swico.ch or www.sens.ch.

B. Information on Disposal for Business Users

1. In the European Union

If the product is used for business purposes and you want to discard it:

Please contact your SHARP dealer who will inform you about the take-back of the product. You might be charged for the costs arising from take-back and recycling. Small products (and small amounts) might be taken back by your local collection facilities.

For Spain: Please contact the established collection system or your local authority for take-back of your used products.

2. In other Countries outside the EU

If you wish to discard of this product, please contact your local authorities and ask for the correct method of disposal.

R-879_FC+INTRO EN.qxd 6/4/07 11:49 AM Page 2

CONTENTS

Operation manual

DEAR CUSTOMER 1
RECYCLING INFORMATION 2
OVEN AND ACCESSORIES 4
CONTROL PANEL 5
IMPORTANT SAFETY INSTRUCTIONS GB-1-3
INSTALLATION GB-3
BEFORE OPERATION GB-4
SELECTING THE LANGUAGE GB-4
ENERGY SAVE MODE GB-5
USING THE STOP KEY GB-5
SETTING THE CLOCK GB-6
MICROWAVE POWER LEVELS GB-6
MICROWAVE COOKING GB-7
GRILL COOKING GB-7-8
HEATING WITHOUT FOOD GB-8
CONVECTION COOKING GB-9-10
DUAL COOKING GB-11-12
OTHER CONVENIENT FUNCTIONS GB-13-15
INSTANT ACTION OPERATION (EXPRESS PIZZA/FUN MENUS/AUTO COOK) . . .GB-16
EXPRESS PIZZA CHART GB-17
FUN MENUS CHART GB-17
AUTO COOK CHART GB-18
AUTOMATIC OPERATION (PIZZA/AUTO DEFROST) GB-19-20
PIZZA CHART GB-20
AUTO DEFROST CHART GB-21
RECIPES FOR FUN MENUS GB-22
RECIPES FOR AUTO COOK “GRATINATED FISH FILLET” GB-23
CARE AND CLEANING GB-24
SERVICE CALL CHECK GB-25

Cookbook

WHAT ARE MICROWAVES? . . . . . .GB-X
WHAT YOUR NEW COMBI-MICROWAVE OVEN CAN DO . . . . . .GB-X
SUITABLE COOKWARE . . . . . .GB-XX-XX
TIPS AND TECHNIQUES . . . . . .GB-XX-XX
HEATING . . . . . .GB-XX
THAWING . . . . . .GB-XX
THAWING AND COOKING . . . . . .GB-XX
COOKING OF MEAT, FISH AND POULTRY . . . . . .GB-XX
COOKING FRESH VEGETABLES . . . . . .GB-XX
LEGEND . . . . . .GB-XX
TABLES . . . . . .GB-XX-XX
RECIPES . . . . . .GB-XX-XX

SERVICE ADDRESSES 6-12
SPECIFICATIONS 13

R-879_FC+INTRO EN.qxd 6/4/07 11:49 AM Page 3

OVEN AND ACCESSORIES





1 Control panel
2 Oven lamp
3 Grill heating element (top grill)
4 Waveguide cover
5 Oven cavity
6 Turntable motor shaft
7 Grill heating element (bottom grill)
8 Door seals and sealing surfaces
9 Door opening handle
10 Fan
11 Ventilation openings
12 Power cord
13 Outer cabinet

ACCESSORIES:
Check to make sure the following accessories are provided:
14 Turntable **15** Low Rack (height: 2,5cm)
16 High Rack (height: 10,5cm)
Place the turntable over the turntable motor shaft on the floor of the cavity.
Before first using the turntable and racks, clean with mild soapy water.
Do not cut or scratch the turntable.







WARNING:
The door, outer cabinet, oven cavity, accessories and dishes will become very hot during operation. To prevent burns, always use thick oven gloves.

NOTE:
When you order accessories, please mention the following two items: Part name and model name to your dealer or SHARP authorized service agent.

ENGLISH

R-879_FC+INTRO EN.qxd 6/4/07 11:49 AM Page 4

CONTROL PANEL





Digital display and indicators:

1 **TOP GRILL** indicator
2 **BOTTOM GRILL** indicator
3 **CONVECTION** indicator
4 **MICROWAVE** indicator
5 **COOKING IN PROGRESS** indicator
6 **INFORMATION** indicator
7 **LESS/MORE** indicator

Operating keys:

8 **TIME** keys
Your oven can be programmed for up to 99 minutes and 90 seconds (99.90).

9 **DUAL MODE** key:
- 1 PRESS = MICROWAVE & CONVECTION
- 2 PRESSES = MICROWAVE & TOP GRILL
- 3 PRESSES = MICROWAVE & BOTTOM GRILL

10 **CONVECTION (°C)** key
Press to change the convection setting.

11 **LESS/MORE** keys
12 **AUTO COOK** keys
13 **AUTO DEFROST** key
14 **PIZZA** key
15 **WEIGHT** keys
16 **LANGUAGE** key
17 **START /+1min** key
18 **STOP** key
19 **INFO/CLOCK** key
20 **EXPRESS PIZZA** key
21 **FUN MENUS** keys
22 **GRILL MODE** key:
- 1 PRESS = TOP GRILL
- 2 PRESSES = BOTTOM GRILL
- 3 PRESSES = TOP & BOTTOM GRILL

23 **MICROWAVE POWER LEVEL** key
Press to change the microwave power setting.

R-879_[EN].qxd 6/4/07 3:58 PM Page 1

IMPORTANT SAFETY INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS: READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

To avoid the danger of fire.

The microwave oven should not be left unattended during operation. Power levels that are too high, or cooking times that are too long, may overheat foods resulting in a fire.

This oven is designed for counter top or built-in use.
Do not place the oven in a cabinet. When the oven is to be built-in, the installation frame EBR-5000 licensed by SHARP must be used. This is available from your dealer. Refer to the frame installation instructions or ask your dealer for the proper instruction procedure. Only the use of this frame will guarantee the safety and quality of the product.
The electrical outlet must be readily accessible so that the unit can be unplugged easily in an emergency.
The AC power supply must be 230V, 50Hz, with a minimum 16A distribution line fuse, or a minimum 16A distribution circuit breaker.
A separate circuit serving only this appliance should be provided.
Do not place the oven in areas where heat is generated. For example, close to a conventional oven.
Do not install the oven in an area of high humidity or where moisture may collect.
Do not store or use the oven outdoors.

If smoke is observed, switch off or unplug the oven and keep the door closed in order to stifle any flames.

Utensils should be checked to ensure that they are suitable for use in the oven. See Page GB-XX-XX. Use only microwave safe containers and utensils on microwave modes.

When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.

Clean the waveguide cover, the oven cavity and the turntable after use. These must be dry and free from grease. Built-up grease may overheat and begin to smoke or catch fire.

Do not place flammable materials near the oven or ventilation openings.
Do not block the ventilation openings.
Remove all metallic seals, wire twists, etc., from food and food packages. Arcing on metallic surfaces may cause a fire.
Do not use the microwave oven to heat oil for deep frying. The temperature cannot be controlled and the oil may catch fire.
To make popcorn, use only special microwave popcorn makers.
Do not store food or any other items inside the oven.
Check the settings after you start the oven to ensure the oven is operating as desired.
To avoid overheating and fire, special care must be taken when cooking or reheating foods with a high sugar or fat content, for example, Sausage rolls, Pies or Christmas pudding.
See the corresponding hints in operation manual and the cookery book section.

To avoid the possibility of injury

WARNING:
Do not operate the oven if it is damaged or malfunctioning. Check the following before use:
a) The door; make sure the door closes properly and ensure it is not misaligned or warped.
b) The hinges and safety door latches; check to make sure they are not broken or loose.
c) The door seals and sealing surfaces; ensure that they have not been damaged.
d) Inside the oven cavity or on the door; make sure there are no dents.
e) The power supply cord and plug; ensure that they are not damaged.
If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.
Never adjust , repair or modify the oven yourself. It is hazardous for anyone other than a competent person to carry out any service or repair operation which involves the removal of a cover which gives protection against exposure to microwave energy.

Do not operate the oven with the door open or alter the door safety latches in any way.
Do not operate the oven if there is an object between the door seals and sealing surfaces.

Do not allow grease or dirt to build up on the door seals and adjacent parts. Clean the oven at regular intervals and remove any food deposits. Follow the instructions for "Care and Cleaning" on page GB-24. Failure to maintain the oven in a clean condition could lead to a deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.

Individuals with PACEMAKERS should check with their doctor or the manufacturer of the pacemaker for precautions regarding microwave ovens.

To avoid the possibility of electric shock

Under no circumstances should you remove the outer cabinet.
Never spill or insert any objects into the door lock openings or ventilation openings. In the event of a spill, turn off and unplug the oven immediately, and call an authorised SHARP service agent.
Do not immerse the power supply cord or plug in water or any other liquid.
Do not let the power supply cord hang over the edge of a table or work surface.

ENGLISH

IMPORTANT SAFETY INSTRUCTIONS

Keep the power supply cord away from heated surfaces, including the rear of the oven.
Do not attempt to replace the oven lamp yourself or allow anyone who is not an electrician authorised by SHARP to do so. If the oven lamp fails, please consult your dealer or an authorised SHARP service agent.
If the power supply cord of this appliance is damaged, it must be replaced with a special cord. The exchange must be made by an authorised SHARP service agent.

To avoid the possibility of explosion and sudden boiling:

WARNING: Liquids and other foods must not be heated in sealed containers since they are liable to explode.
Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.

Never use sealed containers. Remove seals and lids before use. Sealed containers can explode due to a build up of pressure even after the oven has been turned off.
Take care when microwaving liquids. Use a wide-mouthed container to allow bubbles to escape.

Never heat liquids in narrow necked containers such as baby bottles, as this may result in the contents erupting from the container when heated and cause burns.

To prevent sudden eruption of boiling liquid and possible scalding:

1. Do not use excessive amount of time (See page GB-XX).
2. Stir liquid prior to heating/reheating.
3. It is advisable to insert a glass rod or similar utensil (not metal) into the liquid whilst reheating.
4. Let liquid stand for at least 20 seconds in the oven at the end of cooking time to prevent delayed eruptive boiling.

Do not cook eggs in their shells, and whole hard boiled eggs should not be heated in microwave ovens since they may explode even after microwave cooking has ended. To cook or reheat eggs which have not been scrambled or mixed, pierce the yolks and the whites, or the eggs may explode. Shell and slice hard boiled eggs before reheating them in the microwave oven.

Pierce the skin of such foods as potatoes, sausages and fruit before cooking, or they may explode.

To avoid the possibility of burns

WARNING: The contents of feeding bottles and baby food jars must be stirred or shaken and the temperature checked before consumption, in order to avoid burns.

Use pot holders or oven gloves when removing food from the oven to prevent burns.
Always open containers, popcorn makers, oven cooking bags, etc., away from the face and hands to avoid steam burns and eruption of boiling.

To avoid burns, always test food temperature and stir before serving and pay special attention to the temperature of food and drink given to babies, children or the elderly. Accessible parts may become hot during use. Young children should be kept away.

Temperature of the container is not a true indication of the temperature of the food or drink; always check the food temperature.
Always stand back from the oven door when opening it to avoid burns from escaping steam and heat.
Slice stuffed baked foods after heating to release steam and avoid burns.

To avoid misuse by children

WARNING:
Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
Children should be supervised to ensure that they do not play with the appliance.
When the appliance is operated in the GRILL, CONVECTION, DUAL, INSTANT ACTION and AUTOMATIC operation (except AUTO DEFROST), children should only use the oven under adult supervision due to the temperature generated.

Do not lean or swing on the oven door. Do not play with the oven or use it as a toy.
Children should be taught all important safety instructions: use of pot holders, careful removal of food coverings; paying special attention to packaging (e.g. self-heating materials) designed to make food crisp, as they may be extra hot.

IMPORTANT SAFETY INSTRUCTIONS

Other warnings
Never modify the oven in any way.
Do not move the oven while it is in operation.
This oven is for home food preparation only and may only be used for cooking food. It is not suitable for commercial or laboratory use.**To promote trouble-free use of your oven and avoid damage.**
Never operate the oven when it is empty except where recommended in the operation manual, see Page GB-8. Doing so may damage the oven.
When using a browning dish or self-heating material, always place a heat-resistant insulator such as a porcelain plate under it to prevent damage to the turntable due to heat stress. The preheating time specified in the dish's instructions must not be exceeded.
Do not use metal utensils, which reflect microwaves and may cause electrical arcing. Do not put cans in the oven.
Use only the turntable designed for this oven.
Do not place anything on the outer cabinet during operation.
Do not use plastic containers for microwaving if the oven is still hot from using the **GRILL, CONVECTION, DUAL, INSTANT ACTION** and **AUTOMATIC** operation (except **AUTO DEFROST**), because they may melt. Plastic containers must not be used during above modes unless the container manufacturer says they are suitable.

NOTE:
If you are unsure how to connect your oven, please consult an authorised, qualified electrician.
Neither the manufacturer nor the dealer can accept any liability for damage to the oven or personal injury resulting from failure to observe the correct electrical connection procedure.
Water vapour or drops may occasionally form on the oven walls or around the door seals and sealing surfaces. This is a normal occurrence and is not an indication of microwave leakage or a malfunction.

INSTALLATION

1. Remove all packing materials from the inside of the oven cavity. Discard the loose polythene sheet from between the door and cavity. Remove the feature sticker, if attached, from the outside of the door.



✓ Remove this film

2. Check the oven carefully for any signs of damage.

3. Place the oven on a flat, level surface strong enough to support the oven's weight plus the heaviest item likely to be cooked.
This oven is designed for countertop or built-in use. Do not place the oven in a cabinet. When building the oven into a kitchen unit, see "To avoid the danger of fire" on page GB-1.

4. The oven door may become hot during cooking. Place or mount the oven so that the bottom of the oven is 85 cm or more above the floor. Keep children away from the door to prevent them burning themselves.

5. Do not allow the power supply cord to run over any hot or sharp surfaces, such as the hot air vent area at the top rear of the oven.

6. Ensure there is a minimum of free space above the oven of 19 cm.



7. Securely connect the plug of the oven to a standard earthed (grounded) household electrical outlet.

ENGLISH

BEFORE OPERATION

Your oven comes pre-set for Energy Save Mode so when you first plug it in nothing will appear on the digital display.

To operate the oven in Energy Save Mode:

1. Plug in the oven. Nothing will appear on the display at this time.
2. Open the door. The oven display will show "SELECT LANGUAGE" in 6 languages.
3. Close the door.
4. Select a language (see below).
5. Heat the oven without food (See page GB-8).

NOTE:
You can change to Clock Set Mode if you prefer, see page GB-6 of the operation manual. If you decide to set the clock, Energy Save Mode does not work.

COOKING HINTS:
Your oven has an 'Information Display System' which allows you to access step by step instructions for each of the ovens features/keys. Instructions will appear in the digital display each time you press a key to inform you of the next operation step.

In Energy Save Mode, if you do not operate the oven for 3 minutes or more (i.e. closing the door, pressing the **STOP** key, or at the end of cooking), you will not be able to operate the oven until you open and close the oven door.

SELECTING THE LANGUAGE

Press **LANGUAGE** key	LANGUAGE
once	ENGLISH
twice	DEUTSCH
3 times	NEDERLANDS
4 times	FRANCAIS
5 times	ITALIAN
6 times	ESPANOL

Your oven initially has English selected as the language. To change to a language of your choice, scroll through the options available by pressing the **LANGUAGE** key as shown in the table opposite. Then press the **START** ◊ **/+1min** key.

Example:
Suppose you want to select **Italian**.

1. Choose the desired language

x5

2. Start the setting.

x1

Check the display.

NOTE: The selected language will be memorised, even if the electrical power supply is interrupted.

ENERGY SAVE MODE

Your oven has two operating modes, Energy Save Mode and Clock Set Mode.
The difference between them is that when you are not using the oven, in Energy save Mode nothing will appear on the digital display and in Clock Set Mode the time will be shown.

In Energy Save Mode, if you do not operate the oven for 3 minutes or more (i.e. closing the door, pressing the **STOP** key, or at the end of cooking), you will not be able to operate the oven.
To restore power on, open the door.

If you set the clock, energy save mode will be cancelled.

To start energy save mode manually, follow the instructions below.

Example:
To start the energy save mode (the current time is 23:35):

1. Make sure the correct time appears on the display. Press the **INFO/CLOCK** key twice.

2. Press the **1 MIN** key once and make sure 0 appears on the display.

3. Press **START** ◈ **/+1min** key. The power will be off and the display will show nothing.



USING THE STOP KEY

Use the **STOP** key to:

1. Erase a mistake during programming.
2. Stop the oven temporarily during cooking.
3. Cancel a programme during cooking, press the **STOP** key twice.

ENGLISH

SETTING THE CLOCK

There are two setting modes: 12 hour clock and 24 hour clock.

1. To set the 12 hour clock, press the **INFO/CLOCK** key twice, as shown:

2. To set the 24 hour clock, press the **INFO/CLOCK** key 3 times, as shown:

Example:

To set the 24 hour clock to 23:35:

1. Choose the 24 hour clock by pressing the **INFO/CLOCK** key 3 times.

2. Set the hours. Press the **TIME** keys until the correct hour is displayed.

3. Change from hours to minutes by pressing the **INFO/CLOCK** key once.

4. Set the minutes. Press the **TIME** keys until the correct minutes are displayed.

5. Press the **INFO/CLOCK** key once to start the clock.

Check the display.

NOTES:

1. Press the **STOP** key if you make a mistake during programming.
2. If the oven is in cooking mode and you wish to know the time of day, touch the **INFO/CLOCK** key. As long as your finger is touching the key, the time of day will be displayed.
3. If the electrical power supply to your microwave oven is interrupted, plug in the oven again, then open and close the door. The display will show: "ENERGY SAVE MODE TO GO OUT OF ENERGY SAVE MODE SET CLOCK". If this occurs during cooking, the programme will be erased. The time of day will also be erased.
4. When you want to reset the time of day, follow the above example again.
5. If you do not set the clock, press the **STOP** key once. ".0" will appear on the display. When the operation of the oven is finished, ".0" will reappear on the display instead of the time of day.
6. If you set the clock, energy save mode does not work.

MICROWAVE POWER LEVELS

Your oven has 5 power levels. To choose the power level, follow the advice given in the recipe section.

900 WATT = 100 % output
630 WATT = 70 % output
450 WATT = 50 % output
270 WATT = 30 % output
90 WATT = 10 % output

To set the microwave power level:

1. Input the time by pressing the **TIME** keys.
2. Select the desired microwave power setting by pressing the **MICROWAVE POWER LEVEL** key.
If the **MICROWAVE POWER LEVEL** key is pressed once, "900W" (100 %) will be displayed. If you miss your desired level, continue pressing the **MICROWAVE POWER LEVEL** key until you reach the level again.

NOTE: If the power level is not selected, the level 900 W (100 %) is automatically set.

MICROWAVE COOKING

Your oven can be programmed for up to 99 minutes and 90 seconds (99.90).

Example:
Suppose you want to heat soup for 2 minutes and 30 seconds on 630 W microwave power.

1. Enter the cooking time by pressing the **TIME** keys.

2. Press the **MICROWAVE POWER LEVEL** key twice for 630 W microwave power.

3. Press the **START** ◊ / **+1min** key once to start cooking.

Check the display.

NOTES:

1. When the door is opened during the cooking process, the cooking time on the digital display stops automatically. The cooking time starts to count down again when the door is closed and the **START** ◊ **/+1min** key is pressed.

2. If you wish to know the power level during cooking, press the **MICROWAVE POWER LEVEL** key. As long as your finger is pressing the **MICROWAVE POWER LEVEL** key, the power level will be displayed.

NOTE FOR REHEATING READY MEALS:
Place the ready meal in a heat-resistant flan dish on the low rack.

GRILL COOKING

Your oven has 2 grill heating elements, and a combination of 3 grill cooking modes. Input the time first then select the desired grill mode by pressing the **GRILL MODE** key as indicated below.

Setting	Press **GRILL MODE** key	Grill Heating Element in Use
GRILL 1	1 2 3 **x1**	Top Grill
GRILL 2	1 2 3 **x2**	Bottom Grill
GRILL 3	1 2 3 **x3**	Top and Bottom Grill together

ENGLISH

GRILL COOKING

Example:

Suppose you want to cook for 5 minutes using the top grill only:

1. Enter the desired cooking time by pressing **TIME** keys.

2. Select the cooking mode by pressing the **GRILL MODE** key once.

3. Press the **START** ◊ **/+1min** key once to start cooking.



1. The high or low racks are recommended when grilling.

2. You may detect smoke or a burning smell when using the grill for the first time, this is normal and not a sign that the oven is out of order. (Please see heating without food below.)

3. After cooking the display may show 'NOW COOLING'.

WARNING: The door, outer cabinet, oven cavity, accessories, dishes and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

HEATING WITHOUT FOOD

You may detect smoke or a burning smell when using the grill(s) or dual cooking for the first time. This is normal and not a sign that the oven is out of order. To avoid this problem, when first using the oven, operate both top and bottom grills without food for 20 minutes.

IMPORTANT: During grill operation, to allow smoke or smells to disperse open a window or switch the kitchen ventilation on. Make sure there is no food in the oven.

1. Enter the required heating time. (20 min.)

1. Press the **GRILL MODE** key three times.

3. Press the **START** ◊ **/ +1min** key once to start heating.

4. The oven will count down. When the oven has finished heating, open the door to cool the oven cavity.

WARNING: The oven door, outer cabinet & oven cavity will become hot. Take care to avoid burns when cooling the oven down after operation.

CONVECTION COOKING

This microwave oven has 10 pre-set oven temperatures which use a combination of the top and bottom grills.

Press **CONVECTION** key	1	2	3	4	5	6	7	8	9	10
Oven Temp (° C)	250	230	220	200	180	160	130	100	70	40

Example 1: To cook with preheating

Suppose you want to pre-heat to 180° C and cook for 20 minutes at 180° C.

1. Enter the desired preheat temperature by pressing the **CONVECTION** key five times. The display will show 180° C.

2. Press the **START** ◊ / **+1min** key once to start preheating.

When the pre-heated temperature has been reached the audible signal sounds, the display will show 180° C, open the door and place the food inside the oven. Close the door.

3. Enter the desired cooking time by pressing **TIME** keys.

4. Press the **START** ◊ / **+1min** key once to start cooking.

Check the display.

NOTES:

1. After preheating, if you want to cook at a different temperature press the **CONVECTION** key until the desired setting appears on the display. In the example above, to change the temperature you would press the **CONVECTION** key after entering the cooking time.
2. When the oven reaches the programmed preheating temperature, it will automatically hold at the pre-heated temperature for 30 minutes. After 30 minutes the display will change to time of day, if set. The selected convection programme will be cancelled.
3. After cooking the oven will automatically cool and the display will show "NOW COOLING".

ENGLISH

CONVECTION COOKING

Example 2: To cook without preheating

Suppose you want to cook at 250° C for 20 minutes.

1. Enter the desired cooking time by pressing **TIME** keys.

2. Enter the desired cooking temperature by pressing the **CONVECTION** key once (250° C).

3. Press the **START ◊ / +1min** key once to start cooking.



Check the display.

NOTES:

1. After cooking the oven will automatically cool and the display will show "NOW COOLING".

2. To change the convection temperature, press the **CONVECTION** key until the desired temperature appears on the display.

3. Temperature measurements taken whilst the oven is in convection mode will differ from the displayed level. This is due to the grill elements turning on and off in order to regulate the oven temperature. This will not affect the cooking results as long as the operation manual and cook book are followed correctly.

WARNING: The door, outer cabinet, oven cavity, accessories, dishes and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

DUAL COOKING

Your oven has 3 **DUAL** cooking modes combining the heat of convection, top grill or bottom grill with the power of the microwave. To select the **DUAL** cooking mode press the **DUAL MODE** key to the desired setting. Generally, dual cooking time shortens the total cooking time.

Setting	Press **DUAL MODE** key	Initial Microwave power	Cooking method
DUAL 1	1 2 3 **x1**	270 W	Convection 250° C
DUAL 2	1 2 3 **x2**	270 W	Top grill
DUAL 3	1 2 3 **x3**	270 W	Bottom grill

NOTES: The power settings are variable:

DUAL 1: The oven temperature can be changed from 40° C to 250° C in ten levels.
Microwave power levels can be changed from 90 W - 450 W in three levels.

DUAL 2 & 3: Microwave power levels can be changed from 90 W - 900 W in five levels.

Example 1:

Suppose you want to cook for 20 minutes on DUAL 1, using 90 W microwave power and 200° C convection.

1. Enter desired cooking time by pressing **TIME** keys.

x2

2. Select the cooking mode by pressing the **DUAL MODE** key once.

x1

3. Press the **MICROWAVE POWER LEVEL** key once for 90 W microwave power.

x1

4. Enter the desired cooking temperature by pressing the **CONVECTION** key 3 times (200° C).

x3

5. Press the **START** ◊ **/+1min** key once to start cooking.

x1

Check the display.

ENGLISH

DUAL COOKING

Example 2:

Suppose you want to cook for 20 minutes on DUAL 2, using 90 W microwave power and TOP GRILL.

1. Enter the desired cooking time by pressing the **TIME** keys.

x2

2. Select the cooking mode by pressing the **DUAL MODE** key twice.

x2

3. Press the **MICROWAVE POWER LEVEL** key once for 90 W microwave power.

x1

4. Press the **START** ⏀ **/+1min** key once to start cooking.

x1

Check the display.

Example 3:

Suppose you want to cook for 20 minutes on DUAL 3, using 90 W microwave power and BOTTOM GRILL.

1. Enter the desired cooking time by pressing **TIME** keys.

x2

2. Select the cooking mode by pressing the **DUAL MODE** key 3 times.

x3

3. Press the **MICROWAVE POWER LEVEL** key once for 90 W microwave power.

x1

4. Press the **START** ⏀ **/+1min** key once to start cooking.

x1

Check the display.

WARNING:
The door, outer cabinet, oven cavity, accessories, dishes and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

NOTES:

1. After cooking, the display may show "NOW COOLING". To clear it, press the **STOP** key.

2. Temperature measurements taken whilst the oven is in convection mode will differ from the displayed level. This is due to the grill elements turning on and off in order to regulate the oven temperature. This will not affect the cooking results as long as the operation manual and cook book are followed correctly.

OTHER CONVENIENT FUNCTIONS

1. MULTIPLE SEQUENCE COOKING

This function allows you to cook using up to 4 manual cooking programmes. For **GRILL, CONVECTION** and **DUAL COOKING** modes, you can programme up to 2 stages in one sequence setting.

Example:
To cook : 2 minutes and 30 seconds on 630W microwave power (Stage 1)
5 minutes using top grill only (Stage 2)

STAGE 1

1. Enter the desired cooking time by pressing **TIME** keys.

x2 **x3**

2. Select the cooking mode by pressing **MICROWAVE POWER LEVEL** key twice.

x2

STAGE 2

3. Enter the desired time by pressing **TIME** keys.

x5

4. Select the cooking mode by pressing the **GRILL MODE** key once.

x1

5. Press the **START** ⏀ **/ +1MIN** key once to begin cooking.

x1

Check the display.

(The oven will begin to cook for 2 minutes and 30 seconds at 630W microwave power, and then for 5 minutes on top grill only).

2. MINUTE PLUS FUNCTION

The **START** ⏀ **/+1MIN** key allows you to operate the two following functions:

a. Direct start

You can directly start cooking on 900 W microwave power level for 1 minute by pressing the **START** ⏀ **/+1MIN** key.

NOTE:
To avoid the misuse by children the **START** ⏀ **/+1MIN** key can be used only within 3 minutes after preceding operation, i.e., closing the door, pressing the **STOP** key or cooking completion.

b. Extend the cooking time.

You can extend the cooking time during manual cooking for multiples of 1 minute if the **START** ⏀ **/+1MIN** key is pressed while the oven is in operation.

ENGLISH

OTHER CONVENIENT FUNCTIONS

3. LESS / MORE keys.
The **LESS** (▼) and **MORE** (▲) keys allow you to easily decrease or increase programmed setting times, (for a less well or more well cooked result), used in automatic operations or cooking time while in operation.

a) Changing the pre-programmed time setting.
Example:
Suppose you want to cook 0.4 kg Grill Skewers using the **AUTO COOK** key and **MORE** (▲) key.

1. Choose the desired result (well cooked) by pressing the **MORE** (▲) key once.

x1

2. Choose the automatic menu and quantity by pressing the **GRILL SKEWERS** key 3 times.

x3

After 2 seconds the oven will start to cook automatically.

Check the display.

NOTE:
To cancel **LESS** or **MORE**, press the same key again.
To change **MORE** to **LESS** simply press the **LESS** (▼) key.
To change **LESS** to **MORE** simply press the **MORE** (▲) key.

b) Adjusting the heating time while oven is operating.
During the manual cooking process, the cooking time can be decreased or increased in 1 minute steps each time the **LESS** (▼) and **MORE** (▲) keys are pressed.

NOTE:
You can use this function for manual cooking only.

4. TO CHECK SETTINGS WHILE THE OVEN IS OPERATING

You can check the power level and the actual oven temperatures ie: when pre-heating.

TO CHECK THE POWER LEVEL:

To check the microwave power level during cooking press the **MICROWAVE POWER LEVEL** key.
The oven continues to count down, although the display shows the power level.

As long as your finger is pressing the key, the power level will be displayed.

TO CHECK THE CONVECTION TEMPERATURE:

To check the convection temperature during cooking press the **CONVECTION** key.
When the oven is pre-heating, you can check the actual oven temperature.

As long as your finger is pressing the key, the convection temperature in ° C will be displayed.

4. **INFORMATION** key

Each key carries useful information. If you wish to get the information, press the **INFO/CLOCK** key before pressing the desired key.

Example:

Suppose you want to get information about AUTO COOK menu, Roast Chicken:

1. Choose the **INFO/CLOCK** key function.

2. Press the **ROAST CHICKEN** key once.



Check the display.

NOTE:

1. The information message will be repeated twice, and then the display will show the time of day, if set.
2. If you want to cancel the information press the **STOP** key.

ENGLISH

INSTANT ACTION OPERATION (EXPRESS PIZZA/ FUN MENUS/AUTO COOK)

These automatic functions are designed to work out the correct cooking mode and cooking time to get the best results. You can choose from the 1 EXPRESS PIZZA, 5 FUN MENUS and 5 AUTO COOK menus. Especially the **EXPRESS PIZZA** function automatically cooks frozen pizza very quickly.



The following steps provide additional information on using these features:

1. In order to prevent the accidental use of the oven, each key can only be input within 3 minutes after cooking completion, closing the door or pressing the **STOP** key.
2. The weight of the food is input by pressing the selected food key multiple times, until the desired weight is displayed (except FUN MENUS "Vegetarian Food" and "Desserts".) Enter the weight of the food only. Do not include the weight of the container.
   For food weighing more or less than the weights given in the cooking chart, cook using PIZZA function (for EXPRESS PIZZA, see pages GB-19-20) or manual operation.
3. The programmed cooking time is an average time. If you want to alter the cooking time, use the **LESS** (▼) or **MORE** (▲) keys before pressing each key (see page GB-14).
   If you want the best pizza result for EXPRESS PIZZA function, use the PIZZA function (P-1 Frozen Pizza), see pages GB-19-20.
4. There is no need to press the **START** key as the oven will automatically start to cook after the weight has been input.

When action is required (e.g. to turn food over) the oven stops, the audible signals sound and the display shows the necessary action. To continue cooking, press the **START** ⏀ **/+1min** button.

NOTE:
The final temperature will vary according to the initial temperature, i.e. whether it was chilled or at room temperature. Check food is piping hot after cooking. If necessary, you can extend the cooking time manually.

WARNING: The door, outer cabinet, oven cavity, accessories, dishes and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

Example: To cook Frozen Pizza 0,3 kg using the **EXPRESS PIZZA** key.

1. To select the menu and weight range required, press the **EXPRESS PIZZA** key once.

EXPRESS PIZZA **x1** ⇨ After 2 seconds the oven will start to cook automatically.

EXPRESS PIZZA CHART

KEY	MENU	WEIGHT (Increasing Unit) / UTENSILS	PROCEDURE
EXPRESS PIZZA	Express Frozen Pizza EXPRESS "Stone oven" Pizza (thin base, pre-baked)	0,3/0,35/0,4 kg (50 g) (initial temp -18° C) Directly on the turntable	• Remove the ready prepared frozen pizza from the packaging and place on the turntable. • After cooking, place on a plate for serving.

FUN MENUS CHART

KEY	MENU	WEIGHT (Increasing Unit) / UTENSILS	PROCEDURE
	Frozen Baguettes e.g. Baguettes with Pizza topping	0,15 - 0,50 kg (50 g) (initial temp -18° C) Directly on the turntable	• Remove the deep frozen baguettes from the packaging and place on the turntable. • After cooking, place on a plate for serving.
	Fish Fingers	0,20 - 0,50 kg (50 g) (initial temp -18° C) Directly on the turntable	• Remove the deep frozen fish fingers from the packaging and place on the turntable. • After cooking, place on a plate for serving.
	French Fried Potatoes (recommended for conventional ovens) e.g Standard and thick type	0,20 - 0,40 kg (50 g) (initial temp -18° C) Directly on the turntable	• Remove the deep frozen French fried potatoes from the packaging and place in one layer on the turntable. • For thick French fried potatoes, use the **MORE** (▲) key. • After cooking, place on a plate for serving.
	Vegetarian Food	(initial temp 20° C) Gratin dish Low rack	• See recipes for Vegetarian Food on page GB-22.
	Desserts e.g. Fruit Crumble	(initial temp 20° C) Gratin dish Low rack	• See recipe for Desserts on page GB-22.

ENGLISH

AUTO COOK CHART

KEY	MENU	WEIGHT (Increasing Unit) / UTENSILS	PROCEDURE
	Grill Skewers See recipes on page GB-XX.	0,2 - 0,8 kg (100 g) (initial temp 5° C) High rack	• Prepare the grill skewers. • Place on the high rack and cook. • When the audible signal sounds turn over. • After cooking, place on a plate for serving.
	Roast Chicken Ingredients for 1,2 kg grilled chicken: Salt and Pepper, 1 tsp sweet paprika, 2 tbsp oil	0,9 - 1,8 kg (100 g) (initial temp 5° C) Low rack	• Mix the ingredients and spread on the chicken. • Pierce the skin of the chicken with a fork. • Put chicken, breast side down, on the low rack. • When audible signals sound, turn the chicken over. • After cooking, leave for approx. 3 minutes in the oven, remove and put on a plate for serving.
	Gratinated Fish Fillet	0,6 - 1,2 kg* (100 g) (initial temp fish 5° C) Gratin dish Low rack	• See recipes for Gratinated Fish Fillet on page GB-23. * Indicates the total weight of all ingredients.
	Gratin See recipes on page GB-XX.	0,5 - 1,5 kg* (100 g) (initial temp 20° C) Gratin dish Low rack	• Prepare the gratin. • Place the gratin on the low rack. • After cooking, let the food stand, wrapped in aluminium foil, for approx. 5 minutes. * Indicates the total weight of all ingredients.
	Cake See recipes on page GB-XX.	0,5 - 1,5 kg* (100 g) initial temp 20° C) Cake tin Low rack Saucer	• Prepare the cake. • Place the cake tin on the low rack and put a saucer between the low rack and the tin. • After cooking, remove and stand for approx. 10 minutes.

AUTOMATIC OPERATION (PIZZA/AUTO DEFROST)

These automatic functions are designed to work out the correct cooking mode and cooking time to get the best results. You can choose from the 3 PIZZA and 5 AUTO DEFROST menus.

PIZZA key

AUTO DEFROST key

WARNING: For PIZZA:
The door, outer cabinet, oven cavity, accessories, dishes and especially the grills will become very hot during operation. To prevent burns, always use thick oven gloves.

The followings provide additional information on using this feature:

1. The menu you wish to use can be selected by pressing the **PIZZA** or **AUTO DEFROST** key until the desired menu number is displayed.

2. The weight of the food can be input by pressing the **WEIGHT** keys until the desired weight is displayed. Enter the weight of the food only. Do not include the weight of the container.
For food weighing more or less than weights/ quantities given in the cooking chart, cook using manual operation.

NOTE:
If the **DOWN** (-) **WEIGHT** key is pressed the display will count down from the highest weight range, each time the key is pressed.
If the **UP** (+) **WEIGHT** key is pressed the display will count up from the lowest weight range, each time the key is pressed.

3. Press the **START** ◊ **/+1min** key to start cooking.

4. The programmed cooking times are average times. If you want to alter cooking times pre-programmed in the automatic operations, use the **LESS** (▼) or **MORE** (▲) keys. (See page GB-14.) For best results follow the cooking chart instructions, pages GB-20-21.

When action is required (e.g. to turn food over) the oven stops, the audible signals sound and the display shows the necessary action. To continue cooking, press the **START** ◊**/+1min** key.

Example:

1.

PIZZA key

2.

WEIGHT keys

3.

START ◊ **/+1min** key

4.

LESS/MORE keys

The final temperature will vary according to the initial temperature, i.e. whether it was chilled or at room temperature. Check food is piping hot after cooking. If necessary, you can extend the cooking time manually.

ENGLISH

AUTOMATIC OPERATION (PIZZA/AUTO DEFROST)

The **PIZZA** and **AUTO DEFROST** keys offer the possibility to cook foods quickly and easily.
Example: Suppose you want to cook Frozen Pizza weighing 0.40 kg using the **PIZZA** key.

1. Choose the PIZZA menu by pressing the **PIZZA** key once.

2. Enter the weight by pressing the **WEIGHT** keys until the desired weight is displayed.

3. Press the **START** ◊ **/ +1min** key to start cooking.



PIZZA CHART

KEY	MENU	WEIGHT (Increasing Unit) / UTENSILS	PROCEDURE
PIZZA x1	**P-1 Pizza** Frozen Pizza "Stone oven" Pizza (thin base, pre-baked)	0,15 - 0,60 kg (50 g) (initial temp -18° C) Directly on the turntable	• Remove the ready prepared frozen pizza from the packaging and place on the turntable. For thick base pizza, press the **MORE** (▲) key. • After cooking, place on a plate for serving.
PIZZA x2	**P-2 Pizza** Chilled Pizza	0,15 - 0,45 kg (50 g) (initial temp 5° C) Directly on the turntable	• Remove the ready prepared chilled pizza from the packaging and place on the turntable. • After cooking, place on a plate for serving.
PIZZA x3	**P-3 Pizza** Fresh Pizza e.g. Homemade Pizza	0,7 - 1,0 kg (100 g) (initial temp 20° C) Directly on the turntable	• Prepare the pizza following the recipe below. • Place directly on the turntable. • After cooking, place on a plate for serving.

PIZZA RECIPE

Ingredients:

300 g Approx.	Ready prepared dough (Ready mix or roll out dough.)
200 g Approx.	Tinned tomatoes
150 g	Topping as desired (e.g. corn, ham, salami, pineapple)
50 g	Grated cheese
	Basil, oregano, thyme
	salt, pepper

Procedure:

1. Prepare the dough according to the manufacturer's instructions. Roll out to the size of the turntable.
2. Lightly grease the turntable and place the pizza base on it and pierce the dough.
3. Drain the tomatoes and cut into pieces. Season the tomatoes with the herbs and spread on the dough. Put all other ingredients on the pizza and finally cover with the cheese.
4. Cook on **P-3 Pizza** "Fresh Pizza".

AUTO DEFROST CHART

KEY	MENU	WEIGHT (Increasing Unit) / UTENSILS	PROCEDURE
x1	**AD-1 Defrost** Steaks and Chops	0,2 - 1,0 kg (100 g) (initial temp -18° C) (See note below) Plate	• Place the food on a plate in the centre of the turntable. • When the oven stops and the audible signals sound, turn the food over, rearrange and separate. Shield thin parts and warm spots with aluminium foil. • After defrosting, wrap in aluminium foil for 10 - 20 minutes, until thoroughly defrosted.
x2	**AD-2 Defrost** Minced Meat	0,2 - 1,0 kg (100 g) (initial temp -18° C) (See note below) Plate	• Place the block of minced meat on a plate in the centre of the turntable. • When the oven stops and the audible signals sound, turn the food over. Remove the defrosted parts if possible. • After defrosting, cover with aluminium foil and stand for 5 - 10 minutes, until thoroughly defrosted.
x3	**AD-3 Defrost** Poultry	0,9 - 2,0 kg (100 g) (initial temp -18° C) (See note below) Plate	• Place a plate upside down on the turntable and put the poultry, breast side down, on the plate. • When the oven stops and the audible signals sound, turn the food over. Shield thin parts and warm spots with aluminium foil. • After defrosting, rinse with cold water, cover with aluminium foil and stand for 30 - 60 minutes, until thoroughly defrosted. • Finally clean the poultry under running water.
x4	**AD-4 Defrost** Cake	0,1 - 1,4 kg (100 g) (initial temp -18° C) Flat dish	• Remove all packaging from the cake. • Place on a flat dish in the middle of the turntable. • After defrosting, cut the cake into similar sized pieces keeping space between each piece and let stand for 15 - 70 minutes until evenly defrosted.
x5	**AD-5 Defrost** Bread	0,1 - 1,0 kg (100 g) (initial temp -18° C) Flat dish (Only sliced bread is recommended for this programme.)	• Distribute on a flat dish in the centre of the turntable. • When the audible signal sounds rearrange, and remove defrosted slices. • After defrosting separate all slices and distribute on a large plate. Cover the bread with aluminium foil and let stand for 5 - 20 minutes until thoroughly defrosted.

NOTE: Auto Defrost
1. Steaks and Chops should be frozen in one layer.
2. Minced meat should be frozen in the thin shape.
3. After turning over, shield the defrosted portions with small, flat pieces of aluminium foil.
4. The poultry should be processed immediately after defrosting.
5. For Steaks, Chops, Minced Meat and Poultry arrange the food in the oven as shown below:



ENGLISH

RECIPES FOR FUN MENUS

VEGETARIAN FOOD
Stuffed Courgettes

Ingredients:

4	courgettes of same size (total weight: 700-900 g)
2	bunches spring onions
4	tomatoes (400 g)
200 g	feta cheese, diced
40 g	rusk
1	egg
	salt and pepper
10 g	butter or margarine for greasing the pan

For the sauce:

150 ml	vegetable stock
100 ml	cream
62,5 g	soft cheese
25 g	sunflower kernel

Procedure:

- Wash the courgettes, cut lengthwise into half, remove the pins, take off the inside and dice it. Wash the spring onions and cut them into small slices. Boil over the tomatoes, peel and dice.
- Beat the egg, season with salt and pepper, crumble the rusk in it and mix all together with diced tomatoes, feta cheese, the diced courgettes and half of the spring onions.
- Grease the gratin dish, put the half courgettes in it and fill them with the mixture.
- Place the gratin dish on the low rack and cook on **FUN MENUS** "Vegetarian food" .
- Meanwhile beat together vegetable stock, cream and soft cheese and add the remaining spring onions. When the audible signals sound and the oven stops, add the sauce, and sprinkle over the sunflowerkernel and press the **START** key.
- After cooking, let stand for 5 minutes.

VEGETARIAN FOOD
Stuffed Pepper

Ingredients:

4	small red peppers
2	onions
200 g	fresh mixed mushrooms
2	eggs
100 g	emmenthal cheese, grated
25 g	bread crumbs
	bunch citril finch (leaves of citron)
	bunch parsley
	salt, pepper and nutmeg
10 g	butter or margarine for greasing the pan

For the sauce:

240 g	small can peeled tomatoes, drain well
100 g	Crème fraîche
150 ml	white wine
	herbs of the provence

Procedure:

- Cut the red peppers lengthwise into half, remove the stalks and pins, wash and dry. Cut the onions into small cubes and mix together with the sliced mushrooms.
- Beat eggs and mix with emmenthal cheese, bread crumbs, onions, mushrooms and finely chopped herbs. Season the mixture and fill the red peppers.
- Put the stuffed peppers in a greased gratin dish, place the gratin dish on the low rack and cook on **FUN MENUS** "Vegetarian food" .
- Meanwhile mix together tomatoes with Crème fraîche, white wine and herbs. When the audible signals sound and the oven stops, add the sauce and press the **START** key.
- After cooking, let stand for 5 minutes.

DESSERTS
Raspberry, Apple and Almond Crumble

Ingredients:

For the filling:

250 g	frozen raspberries
2	eating apples, peeled and thinly sliced
50 g	brown sugar
15 ml	Crème de cassis

For the crumble:

75 g	butter
125 g	plain flour
100 g	chopped almonds
75 g	caster sugar

Procedure:

- Place raspberries, apples sugar and crème de cassis in a gratin dish and mix well. Heat for 5 minutes on 900 W, stir after half of cooking time.
- Meanwhile prepare the crumble. Rub the butter into the flour until mixture resembles fine breadcrumbs, stir in the chopped almonds and caster sugar.
- Spoon the crumble evenly on top of the fruit. Place on the low rack and cook on **FUN MENUS** "Dessert" .

HINT: You can use tinned cherries (200 g) or tinned peaches (200 g) instead of frozen raspberries, apples and brown sugar. In this case it is not necessary to precook the fruits.

RECIPES FOR AUTO COOK "GRATINATED FISH FILLET"

GRATINATED FISH FILLET
Fish Gratin Italian Style

Ingredients:
600 g Rose Fish Fillet
250 g Mozarella. approx
250 g tomatoes
2 tbsp. anchovy butter
salt and pepper
1 tbsp chopped basil
lemon juice of 1/2 lemon
2 tbsp chopped mixed herbs
75 g grated Gouda (45 % fat)
sauce thickening powder

Procedure:
- Wash the Fish and dry. Sprinkle with lemon juice and salt and grease with the anchovy butter.
- Place in an oval gratin dish (32 cm).
- Sprinkle the gouda over the fish.
- Wash the tomatoes and remove the stalks. Cut into slices and place on top of the cheese.
- Season with salt, pepper and the mixed herbs.
- Drain the mozarella, cut into slices and place on the tomatoes. Spread over the basil.
- Place the gratin dish on the low rack and cook on **AUTO COOK** "Gratinated Fish Fillet" (1,2 kg) .

Hint: After cooking remove the fish from the gratin dish and stir in some sauce thickening powder. Cook again for 1-2 minutes on 900 W power.

GRATINATED FISH FILLET
Gratinated Rose Fish Fillets 'Esterhazy'

Ingredients:
600 g Rose Fish Fillet
250 g Leeks
50 g onion
100 g carrot
1 tbsp. butter
salt, pepper and nutmeg
2 tbsp. lemon juice
125 g crème fraîche
100 g grated Gouda (45 % fat)

Procedure:
- Wash the leeks and divide in 2 parts from top to bottom. Cut into thin strips.
- Peel the onions and carrots and cut into thin strips.
- Put the vegetables, butter and spices into a casserole dish and mix well. Cook for 5-6 minutes on 900 W power. Stir once in-between cooking.
- In the meantime wash the fish fillet, dry and sprinkle with lemon juice and salt.
- Mix the Crème fraîche under the vegetables and season again.
- Put half of the vegetables in an oval gratin dish (32 cm). Place the fish on top and cover with the remaining vegetables.
- Spread over the Gouda and place on the low rack. Cook on **AUTO COOK** "Gratinated Fish Fillet" (1,2 kg) .

GRATINATED FISH FILLET
Gratinated Rose Fish - Broccoli.

Ingredients:
500 g Rose Fish Fillet
2 tbsp. lemon juice
1 tbsp. butter
2 tbsp flour
300 ml milk
chopped dill, pepper and salt
250 g frozen broccoli
100 g grated Gouda (45 % fat)

Procedure:
- Wash the fish fillet and dry. Sprinkle with lemon juice and salt.
- Heat together butter and flour in a casserole dish without cover for 1-1½ mins on 900 W power.
- Add the milk and stir well. Cook again without cover for 3-4 minutes on 900 W power. After cooking stir and season with dill, salt and pepper.
- Defrost the broccoli in a casserole dish for 4-6 mins on 900 W power. Once defrosted, place the broccoli into a gratin dish (32 cm) and put the fish on top and season.
- Pour the sauce over and sprinkle over the cheese
- Place on low rack and cook on **AUTO COOK** "Gratinated Fish Fillet" (1,1 kg) .

NOTE:

These indications are for 1,2 kg(1,1 kg). If you want to cook other weight, you have to adjust the ingredients.

ENGLISH

R-879_[EN].qxd 6/4/07 3:59 PM Page 24



CARE AND CLEANING

CAUTION: DO NOT USE COMMERCIAL OVEN CLEANERS, STEAM CLEANERS, ABRASIVE, HARSH CLEANERS, ANY THAT CONTAIN SODIUM HYDROXIDE OR SCOURING PADS ON ANY PART OF YOUR MICROWAVE OVEN.

Before cleaning, make sure the oven cavity, door, oven cabinet and accessories are completely cool.

CLEAN THE OVEN AT REGULAR INTERVALS AND REMOVE ANY FOOD DEPOSITS - Keep the oven clean, or the oven could lead to a deterioration of the surface. This could adversely affect the life of the appliance and possibly result in a hazardous situation.

Oven exterior

The outside of your oven can be cleaned easily with mild soap and water. Make sure the soap is wiped off with a moist cloth, and dry the exterior with a soft towel.

Oven controls

Open the door before cleaning to de-activate the oven controls. Care should be taken when cleaning the oven control. Using a cloth dampened with water only, gently wipe the panel until it becomes clean. Avoid using excessive amounts of water. Do not use any sort of chemical or abrasive cleaner.

Oven Interior

1. For cleaning, wipe any splatters or spills with a soft damp cloth or sponge after each use while the oven is still warm. For heavier spills, use a mild soap and wipe several times with a damp cloth until all residues are removed. Built-up splashes may overheat and begin to smoke or catch fire, and cause arcing. Do not remove the waveguide cover.
2. Make sure that mild soap or water does not penetrate the small vents in the walls which may cause damage to the oven.
3. Do not use spray type cleaners on the oven interior.
4. Heat up your oven regularly by using the convection and grill, refer to "Heating without food" on page GB-8. Remaining food or fat splashed can cause smoke or bad smell.

Accessories

The accessories should be washed in a mild washing up liquid solution and dried. They are dishwasher safe.

Door

To remove all trace of dirt, regularly clean both sides of the door, the door seals and adjacent parts with a soft, damp cloth. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.

NOTE: Keep the waveguide cover and accessories clean at all times. If you leave grease or fat in the cavity or accessories, it may overheat, cause arcing, smoke or even catch fire when next using the oven.

SERVICE CALL CHECK

PLEASE CHECK THE FOLLOWING BEFORE CALLING FOR SERVICE:

1. Power Supply:
Check the power plug is properly connected to a suitable wall outlet.
Check the line fuse/circuit breaker is functioning properly.

2. When the door is opened, does the oven lamp turn on? YES _____ NO _____

3. Place a cup of water (approx. 150 ml) in the oven and close the door securely.
Programme the oven for one minute on 900 W microwave power and start the oven.
Does the oven lamp come on? YES _____ NO _____
Does the turntable rotate? YES _____ NO _____
NOTE: The turntable turns in either direction.
Does the ventilation work? YES _____ NO _____
(Place your hand over the ventilation openings and check for air flow.)
After 1 minute does the signal sound? YES _____ NO _____
Does the cooking in progress indicator go off? YES _____ NO _____
Is the cup of water warm after the above operation? YES _____ NO _____

4. Take the cup of water out of the oven and close the door. Set the GRILL cooking mode using the top and bottom grills for 3 minutes.
After 3 minutes do both GRILL heating elements become red? YES _____ NO _____

If you answer "NO" to any of the above questions, call a Service Technician appointed by SHARP and report the results of your check. See inside back cover for details of address.

IMPORTANT: If the display shows nothing even if the power supply plug is properly connected, the energy save mode may be in operation. Open and close the oven door to operate the oven. See GB-5.

NOTE:

1. If you cook the food over the standard time with only the same cooking mode, the power of the oven will lower automatically to avoid overheating. (The microwave power level will be reduced and the grill heating elements will begin to light on and off.)

Cooking mode		Standard time
Microwave 900 W cooking		20 min.
Grill cooking TOP GRILL BOTTOM GRILL TOP and BOTTOM GRILL		 15 min. 15 min. Top grill - 6 min. Bottom grill - 6 min.
Dual 2	Microwave 900W	Micro - 20 min. Top grill - 15 min.
	Microwave 90 - 630W	Top grill - 15 min.
Dual 3	Microwave 900W	Micro - 20 min. Bottom grill -15 min.
	Microwave 90 - 630W	Bottom grill - 15 min.

2. After the GRILL, DUAL, CONVECTION, INSTANT ACTION and AUTOMATIC OPERATION (except AUTO DEFROST), the cooling fan will run and "NOW COOLING" will appear on the display. Also, when you press the **STOP** key and open the door during the GRILL, DUAL, CONVECTION, INSTANT ACTION and/or automatic cooking (except AUTO DEFROST), the cooling fan will run; you may, therefore, feel air blowing from the ventilation openings.

3. If the display shows messages for "DEMO MODE", or the time in the display is counting down very rapidly, the oven may be set in the demo mode. To cancel the demo mode, unplug the oven from the wall outlet and replug.

ENGLISH

R-879_[EN] Service.qxd 5/15/07 4:32 PM Page 1

• SEULEMENT VALIDE POUR L'ALLEMAGNE ET L'AUTRICHE • SLECHTS GELDIG VOOR DUITSLAND EN OOSTENRUK • • SOLTANTO VALIDO PER LA GERMANIA E L'AUSTRIA • SOLAMENTE VÁLIDO PARA ALEMANIA Y AUSTRIA • ONLY VALID FOR GERMANY AND AUSTRIA •

Vorgehensweise bei Vorliegen eines Produktmangels:

- **Wurde Ihr Gerät durch einen Fachbetrieb mit einem von Sharp genehmigten Einbaurahmen oder rahmenlos ein-/untergebaut, können Sie die unter Ziffer 1. aufgeführten Garantieansprüche im Rahmen des Quick 48 Vor-Ort-Service geltend machen und sich direkt an den KUNDEN-SERVICE wenden oder Sachmängel gegenüber Ihrem Verkäufer geltend machen.**
- **Für alle übrigen Geräte können Sie die unter Ziffer 2. aufgeführten Garantieansprüche ohne Quick 48 Stunden Vor-Ort-Service oder Sachmängel gegenüber Ihrem Verkäufer geltend machen.**

DER SHARP KUNDEN-SERVICE

SHARP QUICK 48 Mikrowellen Vor-Ort-Service

Sie erreichen die Service-Hotline:
montags bis freitags zwischen 8 und 18 Uhr
in Österreich: **0820 - 240 496** (€ 0,145/Min.)
in Deutschland: **0180 - 523 46 74**
(€ 0,14/Min. aus dem Festnetz der T-Com)

1. Garantie mit Quick 48 Stunden Vor-Ort-Service

Gilt für Deutschland und Österreich

Haushalts-Mikrowellengeräte im Quick 48 Stunden Vor-Ort-Service

Sehr geehrter Sharp Kunde,

alle ein-/ untergebauten Haushalts-Mikrowellengeräte, die durch einen Fachbetrieb fachgerecht mit einem von SHARP genehmigten Einbaurahmen oder rahmenlos ein-/ bzw. untergebaut worden sind, werden im Quick 48 Vor-Ort-Service abgewickelt. Die in dieser Garantie beschriebenen Ansprüche stehen Ihnen zusätzlich neben den gesetzlichen Sachmängelansprüchen gegen Ihren Verkäufer zu.

Umfang der Garantie: Sollte Ihr Mikrowellengerät trotz sorgfältiger Herstellung und Endkontrolle einen Mangel aufweisen, können Sie innerhalb der Garantiezeit, Garantieleistungen gegen Sharp Electronics (Europe) GmbH in Anspruch nehmen. Diese stehen Ihnen zu, wenn ein herstellungsbedingter Material- und/oder Verarbeitungsmangel (nachfolgend „Mangel") bei dem Mikrowellengerät oder Teilen davon - mit Ausnahme der Garraum-Glühlampe - innerhalb von 24 Monaten auftritt. Die Garantie umfasst nicht Mängel, die durch unsachgemäße Behandlung, Bedienungsfehler oder durch Fremdeinwirkung entstanden sind. Transportschäden bei Neugeräten müssen Sie bei Ihrem Verkäufer geltend machen. Die Garantiefrist von 24 Monaten beginnt mit dem Tag, an dem Sie das fabrikneue Gerät von einem Händler gekauft haben. Die Erbringung von Garantieleistungen verlängert nicht die Garantiezeit.

Garantieleistungen: Sharp Electronics (Europe) GmbH erfüllt seine Garantieverpflichtungen für Mängel durch kostenlose Reparatur und einen **Quick 48 Stunden Vor-Ort-Service.** Etwa anfallende Transportkosten innerhalb Deutschlands und Österreich übernehmen wir.

Im Quick 48 Stunden Vor-Ort-Service werden alle Reklamationen, die montags bis freitags zwischen 8:00 und18:00 Uhr beim Quick 48 Deutschland, **Tel.: 0180 / 5 23 46 74** *(€ 0,14/Min) und in Österreich **Tel.: 0820 / 240 496** **(€ 0,145/Min) eingehen, ab dem darauffolgenden Werktag gerechnet, im Regelfall innerhalb 48 Stunden bei Ihnen im Vor-Ort-Service repariert.

Geltendmachung der Garantie: Der Mangel des Gerätes muss innerhalb der Garantiefrist unter Angabe des Kaufdatums, der Modellbezeichnung und der Seriennummer des Gerätes unter den oben aufgeführten Telefonnummern geltend gemacht werden. Bei der Vor-Ort-Reparatur ist dann der Kaufbeleg, aus dem sich das Kaufdatum, die Modellbezeichnung und die Seriennummer des Gerätes ergibt, vorzulegen.

Achtung:
Wird dieser Service für von Ihnen selbst ein-/untergebaute Geräte in Anspruch genommen, sind für Aus-/und Einbau, Fahrzeit und Km die entstehenden Kosten von Ihnen zu tragen!
Bitte erkundigen Sie sich vor Anforderung des Kundendienstes bei diesem über die anfallenden Kosten. Den für Sie nächstgelegenen Kundendienst nennt Ihnen gern unsere o.g. Hotline.

Als Nachweis für Sachmängel-/ Garantiearbeiten dient Ihr Kaufbeleg / Rechnung.

Selbstverständlich können Sie unseren QUICK 48 Vor-Ort-Service für Mikrowellengeräte auch nach Ablauf der Verjährungsfristen für Sachmängel-/Garantiefristen in Anspruch nehmen, dann jedoch gegen Aufwandsberechnung des jeweiligen Kundendienstes.

Garantiegeber: SHARP Electronics (Europe) GmbH, Sonninstraße 3, 20097 Hamburg
www.sharp.de

• SEULEMENT VALIDE POUR L'ALLEMAGNE ET L'AUTRICHE • SLECHTS GELDIG VOOR DUITSLAND EN OOSTENRUK • • SOLTANTO VALIDO PER LA GERMANIA E L'AUSTRIA • SOLAMENTE VÁLIDO PARA ALEMANIA Y AUSTRIA • ONLY VALID FOR GERMANY AND AUSTRIA •

Vorgehensweise bei Vorliegen eines Produktmangels:

- **Wurde Ihr Gerät durch einen Fachbetrieb mit einem von Sharp genehmigten Einbaurahmen oder rahmenlos ein-/untergebaut, können Sie die unter Ziffer 1. aufgeführten Garantieansprüche im Rahmen des Quick 48 Vor-Ort-Service geltend machen und sich direkt an den KUNDEN-SERVICE wenden oder Sachmängel gegenüber Ihrem Verkäufer geltend machen.**
- **Für alle übrigen Geräte können Sie die unter Ziffer 2. aufgeführten Garantieansprüche ohne Quick 48 Stunden Vor-Ort-Service oder Sachmängel gegenüber Ihrem Verkäufer geltend machen.**

2. Garantie ohne Quick 48 Stunden Vor-Ort-Service

Gilt für Deutschland und Österreich

Haushalts - Mikrowellengeräte

Wichtiger Endkunden – Hinweis: Serviceabwicklung nur über den Verkäufer. Die in dieser Garantie beschriebenen Ansprüche stehen Ihnen zusätzlich neben den gesetzlichen Sachmängelansprüchen gegen Ihren Verkäufer zu.

Sehr geehrter SHARP Kunde,

SHARP- Geräte sind Markenartikel, die mit Präzision und Sorgfalt nach modernen Fertigungsmethoden hergestellt werden. Bei sachgemäßer Handhabung und unter Beachtung der Bedienungsanleitung wird Ihnen Ihr Gerät lange Zeit gute Dienste leisten. Das Auftreten von Fehlern ist aber nie auszuschließen. Sollte Ihr Gerät innerhalb der gesetzlichen oder mit Ihrem Verkäufer vereinbarten Verjährungsfristen für Sachmängel-/ Garantiefristen einen Mangel aufweisen und das Gerät wurde **nicht von Ihrem Handelspartner ein-/unter-gebaut,** so wenden Sie sich bitte an den Verkäufer, bei dem Sie das Gerät erworben haben und geben Sie das defekte Gerät dort ab, denn dieser ist Ihr Ansprechpartner für Sachmängel.

Umfang der Garantie: Sollte Ihr Mikrowellengerät trotz sorgfältiger Herstellung und Endkontrolle einen Mangel aufweisen, können Sie innerhalb der Garantiezeit, Garantieleistungen gegen Sharp Electronics (Europe) GmbH in Anspruch nehmen. Diese stehen Ihnen zu, wenn ein herstellungsbedingter Material- und/oder Verarbeitungsmangel (nachfolgend „Mangel") bei dem Mikrowellengerät oder Teilen davon - mit Ausnahme der Garraum-Glühlampe - innerhalb von 24 Monaten auftritt. Die Garantie umfasst nicht Mängel, die durch unsachgemäße Behandlung, Bedienungsfehler oder durch Fremdeinwirkung entstanden sind. Transportschäden bei Neugeräten müssen Sie bei Ihrem Verkäufer geltend machen. Die Garantiefrist von 24 Monaten beginnt mit dem Tag, an dem Sie das fabrikneue Gerät von einem Händler gekauft haben. Die Erbringung von Garantieleistungen verlängert nicht die Garantiezeit.

Garantieleistung:

Sharp Electronics (Europe) GmbH erfüllt seine Garantieverpflichtung für Mängel nach seiner Wahl durch kostenlose Reparatur oder durch Austausch des mangelhaften Gerätes gegen ein mangelfreies. Etwa anfallende Transportkosten innerhalb Deutschlands und Österreich werden von uns übernommen.

Geltendmachung der Garantie:

Um die Garantie in Anspruch nehmen zu können, benötigen Sie den Kaufbeleg (Rechnung, Quittung) aus dem sich das Kaufdatum, die Modellbezeichnung und Seriennummer des Gerätes ergibt. Der Mangel des Gerätes muss innerhalb der Garantiefrist von Ihnen gegenüber einem Sharp Service-Partner oder einem autorisierten Händler von Sharp Electronics (Europe) GmbH geltend gemacht werden. Bei weiteren Fragen wenden Sie sich bitte von montags bis freitags zwischen 8:00 und 18:00 Uhr an **unsere Service-Hotline 01805-29 95 29 *** (€ 0,14/Min)

Selbstverständlich können Sie unseren Kundendienst für Sharp-Mikrowellengeräte auch nach Ablauf der Verjährungsfristen für Sachmängel-/Garantiefristen in Anspruch nehmen, dann jedoch gegen Aufwandsberechnung des jeweiligen Kundendienstes.

Garantiegeber: SHARP Electronics (Europe) GmbH, Sonninstraße 3, 20097 Hamburg
www.sharp.de

R-879_[EN] Service.qxd 5/15/07 4:32 PM Page 7

• ADDRESSES D'ENTRETIEN • ONDERHOUDSADRESSEN • DIRECCIONES DE SERVICIO • INDIRIZZI DI SERVIZIO •

BELGIUM - http://www.sharp.be
En cas d´une réclamation concernant une four a micro-onde SHARP, nous vous prions de vous adresser à votre spècialiste ou à une adresse des SHARP Services suivantes.
Indien uw magnetron problemen geeft kunt u zich wenden tot uw dealer of een van de onderstaande Sharp service centra.

SHARP ELECTRONICS, Phone: 0900-10158
AVTC, Kleine Winkellaan 54,1853 Strombeek-Bever, 02/2674019 / **ETS HENROTTE**, Rue Du Campinaire 154, 6240 Farciennes, 071/396290 / **Nouvelle Central Radio (N.C.R)**, Rue des Joncs 15 L-1818 HOWALD, 00352404078 / **Service Center Deinze**, Kapellestraat, 95, 9800 DEINZE, 09-386.76.67

NEDERLAND - http://www.sharp.nl
Indien uw magnetron problemen geeft kunt u zich wenden tot uw dealer of naar onderstaand Sharp Service Centrum.

SHARP ELECTRONICS BENELUX BV,- Helpdesk -,Postbus 900, 3990 DW Houten, 0900-7427723

FRANCE - http://www.sharp.fr
En cas de réclamation pour les fours micro-ondes SHARP, nous vous prions de vous adresser à votre spécialiste ou à l'une des stations techniques agréées SHARP suivantes:

A.A.V.I., 1 rue du Mont de Terre, 59818 Lesquin Cedex, 03.20.62.18.98 / **A.A.V.I. (Point d'Accueil)**, 9-11 rue Léon Trulin, 59000 Lille, 03.20.14.96.20 / **A. P. F.** , 1 rue Gracchus Babeuf 93130 Noisy le Sec, 01.48.43.33.08 / **ATELIER ROUSSEL**, 12 Bld Flandre Dunkerque, 56100 Lorient, 02.97.83.07.41 / **BASTIA TELE VIDEO**, Immeuble Le Béarn - Av. de la libération, 20600 Bastia, 04.95.30.81.29 / **C.M.T.S.**, 38 rue des Ormeaux, 75020 Paris, 01.43.70.20.00 / **ELECTRONIC SERVICE PLUS**, 5 bd LOUIS XI - ZI le Menneton, 37000 Tours, 02.47.77.90.90 / **ELECTRO SERVICE**, 21 rue de Mulhouse- B.P 122, 68313 Illzach, 03.89.62.50.00
ELECTRO TECH, 26 rue Cyrano 69003 Lyon, 0892.691.032 / **M.R.T.**, 74 Rue Albert Einstein - 72021 Le Mans Cedex, 02.43.28.52.20 /
SETELEC, 23 rue de la L'Argilière 76420 Bihorel 02.35.60.64.39 / **S.T.E.**, 3 chemin de l'Industrie, 06110 Le Cannet Rocheville, 04.93.46.05.00 / **TECH SERVICE**, 15 rue du Château de Ribaute, ZA Ribaute 2, 31130 Quint Fonsegrives, 05.62.57.63.90

ITALIA - http://www.sharp.it
Nel caso si verificassero problemi alla vostra apparecchiatura potrete rivolgervi presso un nostro centro di assistenza autorizzato sharp

ABRUZZO: C.A.T. di BELLONE, VIA DELL AREOPORTO,76, TERAMO TE 0861-415745 0861-212117 / **CTR di de Berardinis Vincenzo**, Via G. Cacchi, 18 L'Aquila AQ, 0862-315407 0862-315407 / **CTR di De Berardinis Vincenzo Filiale Avezzano**, Via P. Gobetti, 10 Avezzano AQ, 0862-315407 0862-315407 / **ELETTROVIDEO SNC**, VIA TIBURTINA, 64 PESCARA PE, 085-52020 085-52020 / **MARINANGELI FABRIZIO**, VIA ROCCO CARABBA, 27 L'AQUILA AQ, 0862-310279 0862-322408 / **MARINANGELI FABRIZIO FILIALE DI AVEZZANO**, VIA F.LLI ROSSELLI, 4/A AVEZZANO AQ, 0863-25207 0863-25207

BASILICATA: LD SERVICE, via Viviani 2 Potenza PZ, 0971-472578 0971-472578 / **MATERA ELETTRONICA SNC DI BUONO E. & C.**, VIA E. MAIORANA, 86/88 MATERA MT, 0835-389310 0835-389310

CALABRIA: ATER SNC DI DOMENICO & AURELIO CATALANO, Via Naz. Pentimele 159/a-b Reggio Calabria RC, 0965-47051 0965-47855 / **AUDIOVIDEO SNC DI VARRESE & COSTANTINI**, VIA A. DE GASPERI, 44 VIBO VALENTIA VV, 0963- 45571 0963- 45572 / **BATTAGLIA SAVERIO**, VIA C. COLOMBO, 85 CATANZARO LIDO CZ, 0961-33824 0961-737337 / **CIANO GIUSEPPE**, VIA SECONDA TRAVERSA, 16 TAURIANOVA RC, 0966-643483 0966-614946 / **COZZUPOLI & CRUPI SNC**, VIA R. CAMPI PRIMO TRONCO, 103 REGGIO CALABRIA RC, 0965- 24022 0965-310778 / **EUROTRADING SAS DI AIELLO GAETANO**, VIA TORINO, 121/123 CROTONE KR, 0962- 20889 0962-24254 / **S.A.T.E di DODARO E GERVASI SNC**, VIA DEGLI STADI, 28/F COSENZA CS, 0984- 482337 0984- 482337 / **FAG SERVICE SRL**, VIA MAGENTA, 7 CARIATI MARINA CS, 0983-91843 0983-91943

CAMPANIA: CONGESTRI' IGNAZIO, Via G. Bruno, 8 Maddaloni CE, 0823-437704 0823-437704 / **DRF ELETTR. di RUBBO**, ZONA INDUSTRIALE PEZZAPIANABENEVENTO BN, 0824-21831 0824-21831 / **ELETTRONICA D`ARGENIO**, VIA NAZION. TORRETTE,195 MERCOGLIANO AV, 0825-681590 0825-681590 / **ELETTRONICA NASTI DI BRUNO NASTI**, VIA FERRARECCE PAL. ETA 173/175 CASERTA CE, 0823-443099 0823-356006 / **ELETTRONICA NASTI DI BRUNO NASTI FILIALE**, VIA CILEA, 52 AVERSA CE 081-8113163 / **ELETTRONICA SERVICE SNC**, VIALE EUROPA, 15 CASTELL. DI STABIA NA, 081-8728280 081-8728280 / **ERREDIESSE SERVICE SRL**, VIA P. MASCAGNI, 74/76 NAPOLI NA 081-5794825 081-5791899 / **M.C. ELETTRONICA SNC DI MILITO M.**, Via dei Mille, 138 Salerno SA 089-330591 06233244764 / **NETTI GIANFRANCO**, Via Magna Grecia, 137/139 Capaccio Scalo SA 0828-730071 0828-730071 / **S.A.RI.EL. SAS,** VIA DIOCLEZIANO, 177 NAPOLI NA 081-7628155 081-7628155 / **SE.RI.EL.CO**, V.DELLE MEDAGLIE D'ORO,163 COSENZA CS, 0984-33152 0984-33152

EMILIA ROMAGNA: AUDIO VIDEO CENTER SNC, VIA F. VANDELLI, 23/29 MODENA MO, 059-235219 059-210265 / **BARGELLINI ORAZIO**, VIA LOCCHI, 3/C FORLI' FO, 0543- 701446 0543- 701446 / **CASALIGGI F.LLI SNC**, VIA BOSELLI, 77 PIACENZA PC, 0523-615740 0523-602014 / **ELECTRON SERVICE SNC**, VIA F.LLI AVENTI, 59 FERRARA FE, 0532-903250 0532-903250 / **MA.PI. SNC DI MAURIZI E CAMPAGNOLI**, VIA T.AZZOLINI, 3 BOLOGNA BO, 051-6414115 051-406848 / **NOVATECNICA**, Via Giovenale, 78/A - Viserba di Rimini Rimini RN, 0541-736361 0541-1831497 / **NUOVA CRT DI AUGUSTO BOERI**, VIA MOLINARI, 40 PIACENZA PC, 0523-592345 0523-592345 / **NUOVA TECNOCOOP**, VIA ARMELLINI 28/30/32 BELLARIVA RIMINI RN, 0541-370812 0541-370812 / **PARMASERVICE SAS**, VIA BENEDETTA, 47/A PARMA PR, 0521-271666 0521-271666 / **RAVSERVICE DI RAVEZZI ANGELO**, VIA AVOGADRO, 6/10 BELLARIA RN, 0541-347714 0541-324413 / **RTE SNC DI I. CATELLANI & C. SNC**, Via Premuda, 38/V Reggio Emilia RE, 0522-381277 / **TERMOSERVICE SAS DI BARTOLETTI IMERIO**, VIA DISMANO, 114/N PONTE NUOVO RAVENNA RA, 0544-472001 0544-67837 / **VIDEO 2000 SRL**, VIA DELL-INDUSTRIA, 26 BOLOGNA BO, 051-531581 051-19931146 / **P. & L. DI LELLI MAURO E C. SNC**, VIA TOSCANA, 7 MONTALE RANGONE MO, 059-530300 059-530300 / **REM SNC**, VIA MANFREDI, 110/A PIACENZA PC, 0523 716361 0523 716361

FRIULI VENEZIA GIULIA: A.V.R. SERVICE DI FOCHESATO IVAN MOSE', VIA COLONNA, 20/8 PORDENONE PN, 0434-27669 0434-523661 / **ELECTRONIC SERVICENTER SAS**, VIA GATTERI, 12 TRIESTE TS, 040-3478423 040-3478423 / **STARACE ELIO TECNICASA DI BRANDOLIN DARIO**, Via Caprin, 4 Trieste TS, 040-773718 040-773718

LAZIO: A.P. RIP. ARDUINI PIERO, VIA LICINIO REFICE, 192 FROSINONE FR, 0775-291267 0775-291267 / **CENTRO E.L.VA. SNC**, VIA ATTILIO MORI, 19/21 ROMA RM, 06-2148641 06-2753048 / **CTS centro tecnico specializzato di Rita De Renzi**, Via Rialto, 38/42 Roma RM, 06-39729748 06-39733315 / **ELETTRONICA 81 SNC**, VIA EZIO, 56/58 LATINA LT, 0773-694608 0773 414612 / **ITALREG SRL**, SS FORMIA-CASSINO KM 30,200 LOC PENITRO FORMIA LT 0771-738011 0771-738061 / **PALMIERI F.**, VIA S.POLLEDRARA, 219 FROSINONE FR 0775-291485 0775-291485 / **PANASERVICE SRL**, VIA BARBANA, 35 ROMA RM 06-5403384 06-5401221 / **PANASERVICE SRL FILIALE**, VIA TARCENTO, 27/29 ROMA RM 06-25204806 / **VIDEO**

R-879_[EN] Service.qxd 5/15/07 4:32 PM Page 8

• ADDRESSES D'ENTRETIEN • ONDERHOUDSADRESSEN • DIRECCIONES DE SERVICIO • INDIRIZZI DI SERVIZIO •

SERVICE SAS DI G. CALABRESE & C., Str. Teverina, Km. 2,400 Loc. Pantanese Viterbo VT, 0761-251557 0761-251558 / **VITECART 99 DI TRIPPINI PAOLO**, VIA DELLA PALAZZINA, 103/H VITERBO VT, 0761-220522 0761-220522

LIGURIA: C.R.E. DI ARATELE FABRIZIO, VIA CAMOZZINI, 189R GENOVA VOLTRI GE, 010-6121754 0106100154 / **ELETTROCLIMA DI REBUFFO MARCO**, REGIONE VALLUVAIA, 13 SAN BARTOLOMEO AL MARE IM, 0183-400102 / **MICHELIS SANDRO**, Via Giannetti, 8/10 Imperia IM, 0183-275891 0183-275891 / **RIEN SNC**, Via Valle, 17/19 La Spezia SP, 0187-21925 0187-21925 / **TELESERVICE DI SCALVO N. & C. snc**, VIA PONCHIELLI 27R SAVONA SV 019-810058 019-019-852596 / **TOGNETTI SERVICE DI TOGNETTI MASSIMILIANO**, VIA LUNIGIANA, 589 LA SPEZIA SP 0187-507656 0187-507656 / **VILL@ SNC DI R. VILLA E M.T. ADAMO**, VIA S. CHIARA, 6 R GENOVA GE 010-5740318 010-8630203

LOMBARDIA: 2M DIGITECH SRL, via Rossini 102 DESIO MI, 0362-306557 0362-306148 / **AE CLIMA SERVICE SRL**, VIA GUIDO DA VELATE, 3 MILANO MI, 02-6466930 02-6466930 / **BACCINELLI MARZIO E C. SNC**, VIA BRANZE, 22 BRESCIA BS, 030-2006411 030-2006411 / **CREL SNC**, VIA CARDUCCI SONDRIO SO, 0342-216538 0342-216538 / **EUROTECNICA di RONCHI**, VIA MILANO, 74/B BRESCIA BS, 030-317673 030-317673 / **F.G.R. ELECTRONIC SAS**, VIA R. PELLEGATTA, 34/A VIMERCATE MI, 039-6082592 039-6085034 / **GRANDINI E TORCHIO SNC**, VIA FASOLO, 4 PAVIA PV, 0382-471360 0382-471360 / **MARKET RICAMBI SERVICE SNC**, VIA SAVONA, 43 MILANO MI, 02-48952866 02-4239820 / **MORINI DANIELE**, VIA MAIOCCHI, 10 VOGHERA PV, 0383-368740 0383-368740 / **S.T.A.R.T. VIDEO HI-FI**, VIA ORTI ROMANI, 16/A CREMONA CR, 0372-38731 0372-38731 / **SA.MO di Sacchetto Teresio e c. snc**, Via Spalato, 4 Vigevano PV, 0381-42353 0381-42353 / **TECNOVIDEO SNC**, P.ZZA DE GASPERI, 28 MANTOVA MN, 0376-321554 0376-321554 / **TELETECNICA 2000**, VIA TORINO, 21 GALLARATE VA, 0331-775519 0331-775519 / **TELETECNICA 2000 FIL. VARESE**, VIALE VALGANNA, 178 VARESE VA, 0332-499365 0332-499365 / **VIDEO SERVICES SNC DI VALENTI F. E C.**, Via Locatelli, 2 Seriate BG, 035-296883 035-300076 / **Z BIT SRL**, VIA CHIOGGIA 3 MILANO MI 02-26822804 02-26110301 / **PAGANINI GRAZIANO**, VIA TOLMEZZO, 6 BUSTO GAROLFO MI 0331-566379 0331-566603

MARCHE: CAT DI SCHIARATURA E MORBIDELLI SNC, VIA A. CECCHI, 25 PESARO PS, 0721-25608 0721-25608 / **CENTER SERVICE DI TESTAFERRI**, VIA MATTEO RICCI, 8 ANCONA AN, 071-889660 071-2181171 / **MARCONI LANFRANCO**, VIA M.BIANCO,10 S.BENEDETTO DEL TRONTO AP, 0735-659230 0375-751155 / **S.A.T. RADIO TV**, VIA D. ROSSI, 32-34 MACERATA MC, 0733-231304 0733-230492 / **SAT RADIO TV FIL. ASCOLI**, VIA TEBALDINI, 2 SAN BENEDETTO AP, 0733-231304 0733-230492

MOLISE: TELECOM AUDIO VIDEO SERVICE DI MANOCCHIO G., VIA V. EMANUELE, 67/69 RICCIA CB 0874-716783 0874-716783 / **TELECOM AUDIO VIDEO SERVICE DI MANOCCHIO G. FILIALE**, VIA XXIV MAGGIO, 73 CAMPOBASSO CB 0874-484440 0874-484440

PIEMONTE: ALPILAB DI GIORDANO, CORSO GIOVANNI XXIII, 11 CUNEO CN, 0171-690384 0171-648063 / **ARTE E TECNICA SNC**, VIA FALLETTI, 22 BIELLA BI, 015-8496250 015-8496250 / **ELEKTRO di FIORE F**., C.SO XXVI APRILE, 26 VERCELLI VC, 0161-250071 0161-255843 / **ELTE SNC DI CONTESTABILE NICOLA**, Via Ugo Foscolo, 26 Torino TO, 011-6503786 011-6503786 / **GUIDA di GUIDA ALESSIO**, VIA ROGGIOLO, 5 TRECATE NO 0321-71608 0321-777003 / **MORINI D. SUCCURSALE - A.R. ELETTRONICA SAS**, PIAZZA TORIANI, 12 ALESSANDRIA AL 0131-226212 0131-226212 / **REAT DI FRISINA RITA**, C.SO UNIONE SOVIETICA, 584 TORINO TO, 011-3979817 011-3979817 / **SIRAGUSA E ROAGNA SNC**, C.SO MATTEOTTI,41 ASTI AT 0141-531131 0141-531131 / **VIDEOTEXT DI OBERTO STEFANO**, P.ZZA TRENTO E TRIESTE, 51 CANALE CN, 0173-95878 0173-979638

PUGLIA: ARNESANO FAUSTINO, VIA M.MOSCARDINO, 10 LECCE LE, 0832-318277 0832-318277 / **ASTROTEC P.S.C.A.R.L.**, VIA DEL FEUDO D'ASCOLI, 37 FOGGIA FG, 0881-720921 0881-567123 / **DBF ELETTRONICA DI DI BIASE FARINA EUTERIO**, VIALE OFANTO, 209/D FOGGIA FG, 0881-331126 0881-331126 / **Lamorgese Paolo**, Via Sabotino, 89/91 Bari BA, 080-5421281 080-5428359 / **MICROKEY SRL**, Via Giammatteo, 22 Lecce LE, 0832-399398 0832-399600 / **MICROKEY SRL SUCCURSALE**, Via de giuseppe, 73 Maglie LE, 0836-424813 / **SANTORO ATTILIO**, VIA MARCHE 24 TARANTO TA, 099-335884 099-335884 / **SAT DI PARTIPILO**, VIA BORSELLINO E FALCONE, 17 BIS BARI BA, 080-5022999 080-5022992 / **STEAR DI PICI VINCENZO**, VIA NANNARONE, 2/A FOGGIA FG, 0881-778483 0881-778483 / **TAURISANO SERVICE SRL**, VIA NUMA POMPILIO, 49/55 BRINDISI BR, 0831-564069 0831-522021

SARDEGNA: AS.TEC ELETTRONICA SNC, VIA RIVA VILLASANTA, 227 CAGLIARI CA, 070-524153 070-504109 / **CO.RI.FR.EL. SNC DI AMICO A. & C.**, VIA MONASTIR, 112 CAGLIARI CA, 070-282354 070-272727 / **FLORIS SERGIO**, VIA MAZZINI, 56 GONNESA CA, 0781-45436 0781-469198 / **G.S. ELETTRONICA DI PORCU**, VIA DELLA RESISTENZA, S.N. NUORO NU, 0784-203084 0784-203084 / **LA VIDEO ELETTRONICA SNC DI FAEDDA**, VIA SARDEGNA, 91 ORISTANO OR, 0783-300026 0783-777599 / **VIDEOELETTRONICA SNC DI PEDOL E SABA**, VIA TORINO, 18 SASSARI SS 079- 276616 079-273239 / **BRACCU GAVINO**, VIA DE SIMONE, 9 OLBIA SS, 0789-50114 0789-50114

SICILIA: A.V.S. Elettronica snc, VIA SASSARI, 2/C CATANIA CT, 095- 446696 095-434337 / **ADAMO & C. SNC**, VIA G. FERRARIS, 20 RAGUSA RG, 0932-624553 0932-627191 / **ALAMIA SERVICE PICCOLA COOPERATIVA**, C.SO PISANI, 310/312 PALERMO PA, 091- 6570502 091-6575761 / **ARTE TV sas,** VIA G.CENTORBI, 17 MAZARA DEL VALLO TP, 0923-908160 0923-670035 / **AUDIO VIDEO SRL**, VIA DON MINZONI, 52/54 CALTANISSETTA CL, 0934-552111 0934-552111 / **C.T.A. SERVICE PALERMO**, VIA RAPISARDI, 44 PALERMO PA, 091-343431 091-346488 / **CUPPARI ELECTRONICS**, VIA S.AGOSTINO IS, 265 MESSINA ME, 090- 672064 672065 090-672065 / **CUPPARI ELECTRONICS SUCCURSALE**, VIA LIBERTA', 95 Capo D'Orlando ME 0941-911785 0941-912552 / **ELETTRONICA DI TULLIO MARIA**, VIA CARLENTINI, 40/A SIRACUSA SR, 0931-758602 0931-758602 / **ELETTROSERVICE DI COLOMBO PIERO & C. SNC**, VIA VARIANTE SS 115 KM 338,400 N. 28 MODICA RG, 0932-46169 0932-456169 / **EUROSERVICE 2000**, VIA DEGLI ATLETI 61/C MARSALA TP, 0923-956475 0923-956475 / **G & B CAT DI GABRIELE BARRACO SNC**, VIA COSENZA, 141/151 ERICE TP, 0923-568611 0923-568642 / **GUASTELLA GIUSEPPE**, VIA OLANDA, 11 GELA CL 0933-933976 0933-933976 / **S.A.T.E.L. SERVICE SNC**, CORSO SICILIA, 55 A-C CATENANUOVA EN, 0935-75085 0975-75085 / **SILVESTRO MATTEO DI SILVESTRO ROBERTO E C. SAS**, VIA C. BATTISTI IS 74 MESSINA ME, 090-2932105 090-2932105 / **TRISCARI BARBERI GIUSEPPE**, Via Pindemonte, 97 PRIORO GARGALLO SR, 333 5848485 1782276341 / **VIDEO SERVICE SNC DI DE FRANCISCI E NOLENTINI**, Via P. Nenni, 1 Agrigento AG, 0922-595881 0922-595881

TOSCANA: A.T.E.S. di ZAPPIA L., VIA TORINO, 3/A LIVORNO LI, 0586-859566 0586-859566 / **ARRIGHI RIPARAZIONI DI ARRIGHI SERENA**, VIA F.LLI CERVI, 26/28 P.A ELSA EMPOLI FI 0571-931327 0571-931327 / **ATER DI MUSTACCHIA ANGELO E C. SAS**, VIA AURELIA, 288 ROSIGNANO SOLVAY LI, 0586-762102 0586-768056 / **BARDAZZI PAOLO**, via E. Forlanini 8DR Firenze FI, 055-4376776 055-431956 / **BELCARI ENRICO**, VIA J. GAGARIN, 70 - FORNACETTE PISA PI, 0587-420273 0587420911 / **CATE SNC DI BALDI M. E BUONAMICI G. FIL. CECINA**, C.so Matteotti, 320/a-b Cecina LI, 0586-635071 / **CATE SNC DI BALDI M. E BUONAMICI G. FIL. PRATO**, Via Fiorentina, 76/a-b Prato PO, 0574-632652 0574-4632690 / **CATE SNC DI BALDI M. E BUONAMICI G. SEDE**, Via Segantini, 2 Empoli FI, 0571-80652 0571-944115 / **DBS Elettronica snc di Aldovardi S. & c.**, Via Simon Musico, 2/c Massa MS, 0585-489893 0585-886122 / **ELETTRONICA RNP DI PUCCETTI PAOLO**, VIA ROMANA, 731 LUCCA LU, 0583-956225 0583-956225 / **ERRE TV SERVICE SNC**, VIA GUIDO TARLATI, 11/13 AREZZO AR, 0575-300986 0575-259434 / **LAB.RIPARAZ. FALCHI M.**, VIA A. GARIBALDI, 35/37 PIOMBINO LI, 0565-49400 0565-227161 / **M2 ELETTRONICA DI MORELLI MASSIMO**, VIA DANIMARCA, 3 GROSSETO GR, 0564-454571 0564-454571 / **MGM SERVICE SNC DI MARTINELLI**, Via Paolinelli, 26 - Marlia Capannori LU, 0583-30382 0583-30382 /

R-879_[EN] Service.qxd 5/15/07 4:32 PM Page 9

• ADDRESSES D'ENTRETIEN • ONDERHOUDSADRESSEN • DIRECCIONES DE SERVICIO • INDIRIZZI DI SERVIZIO •

PARIELS SRL, Via B. Tolomei, 8 Siena SI, 0577-51159 0577-589454 / **TELESERVICE DI BENVENUTI STEFANO**, Via E.Fermi 9/13 Prato PO, 0574-580840 / **TELESERVICE DI D'AMICIS E. & V. SNC**, VIA P. PISANA, 71 LIVORNO LI, 0586-400564 0586-409724 / **VIDEO SERVICE DI GENUARDI**, VIA BORGACCIO, 72 POGGIBONSI SI, 0577-983181 0577-996382

TRENTINO ALTO ADIGE: MELONE MICHELE, VIA ZARA, 44 TRENTO TN, 0461-235166 0461-267210 / **SIGHEL MAURO**, VIA A. VOLTA, 92 TRENTO TN, 0461-935919 0461-935919 / **TECNOSERVICE SNC**, VIA SAN VIGILIO, 64/b-c-d BOLZANO BZ, 0471-289062 0471-261559

UMBRIA: QUONDAM C. STEFANO, VIA DEL RIVO, 33 TERNI TR 0744-301512 0744-301512 / **SAT 2000 SNC DI SPARAMONTI PIERO E C.**, Via di Vittorio, 81 Terni TR 0744-279090 0744-279090 / **TECNOCONSULT ELETTRONICA SNC**, VIA MAD.ALTA, 185 PERUGIA PG 075-5003089 075-5003089

VALLE D'AOSTA: CAT DI D'ISANTO, C.SO IVREA, 82/A AOSTA AO, 0165-364056

VENETO: ANDRIOLO SAS DI ANDRIOLO MONICA E NICOLA, VIA VOLONTARI DELLA LIBERTA', 39/A GAMBARARE FR. PIAZZA VECCHIA VE, 041-5675614 041-5675190 / **ASS.ELETTR.CAMPI SNC**, VIA E.REGINATO, 7 TREVISO TV, 0422-436245 0422-435996 / **ASSISTENZA ELETTRON. CAMPI FILIALE MESTRE**, VIA GIUSTIZIA, 32 MESTRE VE, 041-914832 / **ASSISTENZA TECNICA DI MIRCO DE BONA**, VIA MONDINI, 11 BELLUNO BL, 0437-30240 0437-939916 / **DL SERVICE DI DAL LAGO LORENZO**, Via Giaretta, 33 Vicenza VI, 0444 / 966239 0444 / 966239 / **EPS SNC DI TREVISAN E C.**, V.LE GRAMSCI, 134 ROVIGO RO, 0425-33221 0425-30217 / **FRANCHINO GIANFRANCO**, VIA ZERMANESE 6B TREVISO TV, 0422-321054 0422-321054 / **GLOBAL SERVICE IMPIANTI di Cerpelloni & c. snc**, Piazza Plebiscito, 9/A AVESA VR, 045-8342935 045-8342935 / **PIEREZZA CARLO**, VIA BARROCCIO DAL BORGO, 4 PADOVA PD, 049-681592 049-8829059 / **SPEEDY SERVICE DI CORRA' & GIARETTA**, V.le Europa, 42/b Thiene VI, 0445-3`68235 0445-379028 / **VIDEO TV1732**, Via San Marco, 1818 Sottomarina VE, 041-5541675 041-5541675 / **VIDEOSERVICE SNC DI SALVATORI & C.**, VIA VITRUVIO,11 VERONA VR, 045-566299 045-573865 / **ZAFFALON URBANO**, Via Santa Croce, 2040 VENEZIA VE, 041-2750670 041-2757273

ESPANA - http://www.sharp.es
En caso de una reclamación con vuestra SHARP Microwave, preguntan por favor la casa dónde han comprado su máquina o infórmanse en una de las SHARP Service casas siguientes.

ALAVA: MERINO NICOLAS JOSE A., AV JUDIZMENDI 24, 01003 VITORIA-GASTEIZ , 945/ 25.18.92

ALBACETE: JUMAN, CL IGNACIO MONTURIOL 8, 02005 ALBACETE, 967/ 22.40.78 / **JOSE ANT. PARREÑO**, CL FRANCISCANOS 40 , 02003 ALBACETE, 967/ 22.62.49

ALICANTE: ELECTRONICA GOMEZ, CL CAPITAN GASPAR ORTIZ 116 (B), 03204 ELCHE, 96/ 663.42.70 / **TELE-COLOR**, CL DEL VENT 9, 03500 BENIDORM, 96/ 585.24.60 / **ANGEL AVELLAN PUIG**, CL POETA QUINTANA 13, 03004 ALICANTE, 965/ 21.32.55 / **UNISAT**, CL DUQUE DE TAMAMES 9, 03300 ORIHUELA, 96/ 674.11.94 / **TRINITARIO GEA**, CL JAIME POMARES JAVALOYES 47, 03202 ELCHE , 96/ 545.56.25 / **ELECTROSERVICIOS PLAZA**, PZ SANTIAGO 5 , 03300 ORIHUELA , 96/ 828.45.67 / **E.ELECTROSAX**, CL RIO TURIA 1, 03630 SAX , 96/ 547.42.32 / **ASISTEL**, AV DE LA CONSTITUCION 185 D, 03400 VILLENA , 965/ 80.02.31 / **VIDEO ELECTRONICA NOGUERA**, CL CASTELLON 17 , 03590 ALTEA , 965/ 84.41.58 / **JOAQUIN SAEZ SERVICIOS**, CL ESCORPION 6-8 , 03006 ALICANTE , 96/ 528.73.33 / **MATEO BELDA S.L.**, CL CONCORDIA 120, 03180 TORREVIEJA , 966/ 70.49.78 / **EUROSAT SUR**, CL MONTERO RIOS 33 , 03012 ALICANTE , 96/ 525.80.40 / **SERVIELECTRO BENIDORM**, CL MARQUES DE COMILLAS 12 , 03501 BENIDORM / **IMECLIMA**, CL CAVALLER MERITA 21 , 03801 ALCOI

ALMERIA: TELEVIDEO, CL VELAZQUEZ 7 LOCAL-A, 04770 ADRA , 950/ 40.18.63 / **SERVIRAP**, CL ANGEL OCHOTONERA 11, 04005 ALMERIA , 950/ 27.40.67 / **SERVICIO TECNICO PONCE**, PLG PS MARITIMO E- EUROPA 1, 04630 GARRUCHA, 950/ 13.28.37 / **SONIVITEL S.L.**, CL POETA PACO AQUINO 51, 04005 ALMERIA , 950/ 22.97.55

ASTURIAS: ELECTRONICA EDIMAR, S.A, CL CANGAS DE ONIS 4, 33207 GIJON, 98/ 535.34.51 / **ALVAREZ OLIVAR CASILDA**, CL SAN JOSE 12, 33003 OVIEDO, 98/ 522.37.39 / **SANTIAGO VALDERREY**, AV DE LOS EMIGRANTES 34, 37310 NAVIA, 98/ 563.18.61 / **G.A.M.I.F.E.L**, CL RICARDO MONTES 6, 33012 OVIEDO, 98/ 528.43.60 / **ASTUSETEL S.L.**, CL CEA BERMUDEZ 9 , 33208 GIJON , 98/ 539.10.11 / **ASTURSERVICE**, CL SANCHEZ CALVO 6 BJOS., 33401 AVILES, 98/ 556.83.87 / **JUAN MORILLON DEL CORRO**, CL NORTE EDIF. SETSA 5, 33930 LA FELGUERA, 98/ 567.40.24 / **S.A.T. JUAN-MANUEL**, CL URIA 60, 33800 CANGAS DE NARCEA, 98/ 581.22.48 / **MANUEL ALEA VILLA**, CL LLANO MORGOLLES S/N, 33550 CANGAS DE ONIS, 98/ 592.26.40

AVILA: DANIEL SERRAN0 LABRADO, CL JOSE GOCHICOA 16, 05400 ARENAS DE S.PEDRO, 920/ 37.15.16 / **ELECTRONICA GREDOS**, CL EDUARDO MARQUINA 24, 05001 AVILA, 920/ 22.48.39 / **REPARACIONES SAN SEGUNDO**, CL SORIA 6, 05003 AVILA , 920/ 22.33.21

BADAJOZ: ELECTRONICA BOTE, PZ PORTUGAL 2 , 06001 BADAJOZ, 924/ 22.17.40 / **C.E. VILANOVENSE C.B.**, CL CAMINO MAGACELA 4 LOCAL-5, 06700 VILLANUEVA SERENA , 924/ 84.59.92 / **ELECTRONICA CENTENO S.L.**, AV DEL ZAFRA 1, 06310 PUEBLA SANCHO PEREZ, 924/ 57.53.08 / **INDALECIO AMAYA SANCHEZ**, CL CARRERAS 11, 06200 ALMENDRALEJO, 924/ 66.47.01 / **PATRICIO ELECTRONICA**, CL REYES HUERTAS 7, 06800 MERIDA, 924/ 33.04.13

BALEARES (MENORCA): INSAT, CB, CL PINTOR CALBO 30 , 07703 MAHON , 971/ 36.53.18

BALEARES (IBIZA): REPARACIONES ORTEGA, CL VIA ROMANA 17, 07800 IBIZA, 971/ 39.01.55

BALEARES (FORMENTERA) : ELECTRO-SAT, CL EIVISSA 12-16 , 07860 S. FCESC. DE FORMENTERA , 971/ 32.27.62

BALEARES (MALLORCA): INSTALACIONES MAES, S.L., CL SON NADAL 63 , 07008 PALMA DE MALLORCA , 971/ 27.49.47

BARCELONA: VIDEOCOLOR, CL VILLARROEL 44 , 08011 BARCELONA , 93/ 454.99.08 / **ESTARLICH**, CL INDUSTRIA 131, 08370 CALELLA, 93/ 766.22.33 / **CE.VA.SAT**, PS RUBIO I ORS 105, 08203 SABADELL , 93/ 710.76.13 / **LAUREA S.A.T**, CL GUILLERIES BIS 20, 08500 VIC, 93/ 889.02.48 / **CE. VA. SAT, S.C.**, CR MATADEPERA 87 , 08225 TERRASSA , 93/ 785.51.11 / **ELDE**, CL BRUCH 55 , 08240 MANRESA , 93/ 872.85.42 / **SERVINTERS, S.C.C.L.**, PZ CASAGEMES 20 , 08911 BADALONA , 93/ 389.44.60 / **4 EN 1 REPARACIONES**, CL TAQUIGRAFO MARTI 19 , 08028 BARCELONA , 93/ 430.97.26 / **FERMO**, AV MORERA 5 , 08915 BADALONA , 93/ 465.22.00 / **TEELCO**, AV BALMES 90 , 08700 IGUALADA , 93/ 805.11.90 / **ELECTRONICA MATEOS**, CR DE CALDAS (BAJOS) 76 , 08400 GRANOLLERS , 93/ 849.28.77 / **TOP ELECTRONICA**, CL MISSER RUFET 4 bjos , 08720 VILAFRANCA PENEDES , 93/ 890.35.91 / **TOTVISIO ELECTRONICA S.L.**, PJ FERRER 14 , 08240 MANRESA , 93/ 873.88.81 / **LA CLINICA DEL ELECTROD.**, CL BALMES 160 , 08008 BARCELONA , 93/ 236.44.11 / **PULGAR I EDO S.L.**, CL CASANOVA 46 , 08011 BARCELONA , 93/ 436.44.11 / **SERVEI TECNIC FERRER**, CL SARDA 37 , 08203 SABADELL , 93/ 710.51.38 / **FRED VILAFRANCA**, CL PROGRES 42 , 08720 VILAFRANCA DEL PENEDES , 93/ 890.48.52 / **DOMOTICA**, AV DIAGONAL 296 , 08013 BARCELONA , 93/ 408.66.22 / **SALJA & MAT**, CL LA RASETA 15 L-3 , 08750 MOLINS DE REY, 93/ 668.13.61 / **JOAQUIN CASAJOANA PAGES**, CL MAJOR 19 (TIENDA) , 08860 CASTELLDEFELS , 93/

R-879_[EN] Service.qxd 5/15/07 4:32 PM Page 10

664.43.60 / **ESTARLICH**, CL AUQUEBISBE CREUS 12, 08301 MATARO , 93/ 790.22.89 / **TECNOSPLIT S.L.**, CL SANT FRANCESC XAVIER 40 , 08950 ESPLUGUES DE LL. , 93/ 473.57.41 / **SERVITEC**, AV PIUS XII 24, 08500 VIC, 93/ 883.25.11 / **MOVILFRIT**, CL OSCA 11 POL. SALINAS , 08830 SANT BOI DE LL., 96/ 630.14.53

BURGOS: SERVITEC BURGOS S.L., CL VICENTE ALEIXANDRE 23-25, 09007 BURGOS, 947/ 22.41.68

CACERES: RUIZ GARCIA JOSE, CL ECUADOR 5-B , 10005 CACERES , 927/ 22.48.86 / **ARSENIO SANCHEZ, C.B.**, CL TORNAVACAS 9, 10600 PLASENCIA, 927/ 41.11.21 / **RADIO SANCHEZ C.B.**, AV DE MIAJADAS S/N, 10200 TRUJILLO, 927/ 32.06.88

CADIZ: ELECTRONICA Y CLIMATIZACION JEDA, CL DIVINA PASTORA E-1 L-4,5,6, 11402 JEREZ LA FRONTERA, 956/ 33.64.99 / **JOSE M. BORJA PRADOS**, PS VICTORIA EUGENIA 17 Local-1, 11207 ALGECIRAS, 956/ 66.60.53 / **NOVOMAM-SAT**, POL. URBISUR, JORGE JUAN 4, 11130 CHICLANA DE LA FRONTERA , 956/ 40.12.09 / **GALAN SAT S.L.**, CL CRUZ ROJA ESPAÑOLA 11, 11009 CADIZ , 956/ 20.14.17 / **GALAN SAT S.L.**, CL FACTORIA MATAGORDA 52, 11500 PUERTO REAL, 956/ 83.35.35 / **ELECTROGAN**, CL DURANGO 54 , 11500 PTO. STA. MARIA, 956/ 87.07.05 / **SERVITEL**, CL PORVENIR 11 LOCAL , 11401 JEREZ LA FRONTERA , 956/ 33.76.55 / **ROTA ELECTROSUR**, CL MALAGA 11, 11520 ROTA, 956/ 81.59.60 / **J. J. COLLADO NORIEGA**, CL ALMIRANTE M. VIERNA, 11009 CADIZ

CANTABRIA: ELECTRONICA SEYMA, CL CAMILO ALONSO VEGA 48, 39006 SANTANDER, 942/ 32.50.60

CASTELLON: ASISTE, S.L., AV DE VALENCIA NAVE 19, 12006 CASTELLON, 964/ 21.57.69 / **ELECTRONICA MAESTRAT**, PS FEBRER SORIANO 65 , 12580 BENICARLO, 964/ 46.03.08

CEUTA: PEDRO A. CARCAÑO LOPEZ, CL URANO (LOCAL 7) , 51002 CEUTA, 956/ 50.43.99

CIUDAD REAL: ELECTRONICA ARELLANO, CL LORENZO RIVAS 14, 13600 ALCAZAR DE SAN JUAN , 926/ 54.78.95 / **ELECTRODIAZ S.L.**, CL BUENSUCESO 10, 13300 VALDEPEÑAS , 926/ 32.23.24 / **TELE-NUEVA**, CL CAMPO 56, 13700 TOMELLOSO , 926/ 50.59.96 / **CLIMATEC**, CL POZO 3 4º A , 13500 PUERTOLLANO , 652/ 79.03.60 / **SANTIAGO GARRIDO CHAMORRO**, CL LIRIO 41 LOCAL 3, 13004 CIUDAD REAL , 926/ 25.16.05 / **ANJAMA**, AV REY SANTO 28, 13001 CIUDAD REAL , 926/ 92.01.91

CORDOBA: TEODORO DUEÑAS CAÑAS, CL HERMANO JUAN FDEZ 15 , 14014 CORDOBA , 957/ 26.35.06 / **SERPRIEGO S.L.**, CL SAN LUIS 4 BJO. IZDA. , 14800 PRIEGO DE CORDOBA , 957/ 54.15.11 / **CAYRO**, CL HERMANO JUAN FDEZ. 15 , 14014 CORDOBA , 957/ 26.35.06 / **ELECTRONICA SALES**, CL ANDALUCIA 37 , 14920 AGUILAR FRONTERA , 957/ 66.09.04 / **ANTONIO GONZALEZ ESQUINAS**, CL GRAL PRIMO RIVERA 61, 14200 PEÑARROYA , 957/ 57.10.50 / **SONICOR ELECTRONICA** , AV OLLERIAS 43, 14001 CORDOBA

CUENCA : SERVI-TRASGU, CL ALFARERIA 12, 16630 MOTA DEL CUERVO, 967/ 18.10.50 / **INTELCO S.L.**, CL RAMON Y CAJAL 17 , 16004 CUENCA, 969/ 23.39.87

GIRONA: RIERA DAVIU, CL TORRAS Y BAGES 19, 17600 FIGUERES, 972/ 50.32.64 / **NEW MERESA**, CL SURERA BERTRAN 23 , 17200 PALAFRUGELL , 972/ 30.44.54 / **FISATEC**, CL SANT ANTONI 126, 17600 FIGUERES, 972/ 50.09.84

GRANADA: ELECTRONICA WENCESLAO, CL FONTIVEROS 42 , 18008 GRANADA , 958/ 81.16.16 / **DIGIMAT ELECTRONICA**, AV JOSE DE MORA 16 , 18800 BAZA, 958/ 70-04-52 / **FERMASA**, CL AZORIN 7, 18004 GRANADA , 958/ 25.64.77 / **SERVIGON**, CL HOSPITAL DE LA VIRGEN 22, 18015 GRANADA, 958/ 20.52.81 / **SERVICOSTA**, PZ DR. ALVAREZ RIOSOL 1, 18690 ALMUÑECAR, 958/ 63.11.43

GUADALAJARA: TELE-VIDEO MARVI, AV EJERCITO 23, 19004 GUADALAJARA, 949/ 24.86.96

GUIPUZCOA: TEKNIBAT ELECTRONICA, CL ZEZENBIDE 4, 20600 EIBAR , 943/ 70.24.37 / **ELECTRONICA GUIPUZCOANA** , CL BALLENEROS 2 BJOS. , 20011 SAN SEBASTIAN

HUELVA: TELEJARA, POL. POLIRROSA CL-A NAVE-27, 21007 HUELVA , 959/ 22.60.74 / **TELESONID HUELVA, S.C.A.**, CL FCO.VAZQUEZ LIMON 4 , 21002 HUELVA , 959/ 24.38.60 / **AIRSEXT HUELVA**, PS DE LA GLORIETA 6 , 21002 HUELVA , 959/ 22.88.13

JAEN: ELECTRONICA GONZALEZ, CORREDERA SAN BARTOLOME 11, 23740 ANDUJAR , 953/ 50.33.82 / **MANUEL TRILLO**, CL GOYA 1 , 23400 UBEDA , 953/ 75.14.19 / **ELECTRO HIMEGA, S.A.**, CL ADARVES BAJOS 4-C , 23001 JAEN , 953/ 24.22.56 / **ELECTR. MARTINEZ PADILLA**, CL DON LUIS 10 , 23700 LINARES , 953/ 69.52.03

LA CORUÑA: ZENER ELECTRONICA, CL RONDA DE MONTE ALTO 15 , 15002 LA CORUÑA , 981/ 22.07.00 / **S.T. MENDEZ**, CL GIL VICENTE 13 , 15011 LA CORUÑA , 981/ 27.52.52 / **BANDIN AUDIO** , CL URB. A MARTELA 16 , 15920 RIANXO , 981/ 86.60.23 / **RAMSAT** , AV FINISTERRE 117-B , 15270 CEE , 981/ 74.74.61 / **VICTOR PEREZ QUINTELA** , CL ENTRERIOS 35 , 15705 SANTIAGO DE COMPOSTELA , 981/ 58.43.92

LA RIOJA: ELECTRONICA MUSAND, CL REY PASTOR 60-62, 26005 LOGROÑO, 941/ 22.84.52 / **TOP SERVICE**, CL ACHUTEGUI DE BLAS 17, 26500 CALAHORRA, 941/ 13.50.35 / **AGUADO SAT**, CL VELEZ DE GUEVARA 26 BAJO, 26005 LOGROÑO , 941/ 25.25.53

LEON: TECNYSER ELECTRO, CL RELOJERO LOSADA 25 , 24009 LEON , 987/ 22.77.87 / **ASIST. TECNICA MARCOS**, CL CONDE DE TORENO 5, 24006 LEON, 987/ 20.01.01 / **PROSAT (ELECTROBAZAR)**, CL JAIME BALMES 8 , 24007 LEON , 987/ 22.37.30

LLEIDA: JORDI DURO FORT, CL INDUSTRIA 6 3º 3ª , 25620 TREMP, 973/ 65.25.15 / **IELSA ELECTRONICA**, CL TARRAGONA 15, 25005 LLEIDA, 973/ 24.71.27 / **CRISTEL**, CL VALLCALENT 32 , 25006 LLEIDA , 973/ 27.08.26 / **SATEF**, CL SANT PELEGRI 54 , 25300 TARREGA , 973/ 50.08.48 / **ELECTRONICA GUIRAO**, CL SANT PERE CLAVER 16 B-2 , 25300 TARREGA , 973/ 50.02.34 / **ELECTRO FRED PALLARS**, AV ESTACIO 12 , 25500 POBLA DE SEGUR , 973/ 68.04.77

LUGO: ELECTRONICA FOUCES, CL BENITO VICETTO 34 , 27400 MONFORTE DE LEMOS , 982/ 40.24.38 / **TELEVEXO S.L.**, CL NOSA SRA. DO CARMEN 70 , 27880 BURELA, 982/58.18.57 / **ELECTRONICA PENELO**, CL SERRA GANIDOIRA 63 , 27004 LUGO , 982/ 21.47.43 / **SERVICIO TECNICO PASFER**, AV ARCADIO PARDIÑAS 77, 27880 BURELA , 696/17.86.458

MADRID: CROMADELTA, CL ALFONSO XII 31, 28934 MOSTOLES , 91/ 664.16.41 / **GARMAN C.B.**, CL CARLOS SOLE 38 LOCAL , 28038 MADRID , 91/380.33.49 / **ELECTRONICA BARAJAS** , PZ DEL JUBILADO 8 , 28042 BARAJAS , 91/ 305.48.90 / **ELECTRONICA GARMAN, C.B.**, CL MANDARINA 15 , 28027 MADRID , 91/ 368.01.79 / **ELECTRONICA ANSAR**, CL TOMASA RUIZ 4 , 28019 MADRID , 91/ 460.47.45 / **TEC-NORTE**, CL SANTIAGO APOSTOL 5 , 28400 COLLADO VILLALBA , 91/851.63.47 / **VARIOSAT, S.L.**, CL ISLA DE CORCEGA 24 , 28100 ALCOBENDAS , 91/ 662.04.68 / **VIDEO SERVICE ELECTRONIC**, CL ERA HONDA 9, 28803 ALCALA DE HENARES , 91/ 880.27.87 / **UGENASA**, CL LA CANALEJA 4 , 28921 ALCORCON , 91/ 611.52.51 / **ELBESERVI, S.A.**, CL DR.R. CASTROVIEJO 19, 28029 MADRID, 91/ 386.27.11 / **GARMAN C.B.**, CL MANDARINA 15 , 28027 MADRID , 91/ 368.01.79 / **ELBESERVI**, CL DR. R. CASTROVIEJO 19 , 28029 MADRID ,

MALAGA: ELECTRONICA GARCIA CAMPOY, AV VELAZQUEZ 1, 29003 MALAGA , 952/ 32.00.77 / **ELECTRONICA BG**, CL ANDALUCIA 2 , 29670 SAN PEDRO ALCANTARA , 952/ 78.50.09 / **ELECTRONICA RAMA**, PZ DE LAS DESCLZAS 1 , 29200 ANTEQUERA , 952/ 84.42.40 / **REMEDIOS CAMARGO**, CL JUNCO 5 , 29130 ALHAURIN DE LA TORRE

R-879_[EN] Service.qxd 5/15/07 4:32 PM Page 11

• ADDRESSES D'ENTRETIEN • ONDERHOUDSADRESSEN • DIRECCIONES DE SERVICIO • INDIRIZZI DI SERVIZIO •

MELILLA: SONITEV, CL EJERCITO ESPAÑOL 3 , 52001 MELILLA , 952/ 68.30.80

MURCIA: CARO PORLAN RAIMUNDO, CL JOSE MOULIAA 45 , 30800 LORCA , 968/ 46.18.11 / **REG., C.B.**, CL RAMON Y CAJAL 27 , 30205 CARTAGENA , 968/ 51.00.06 / **ELECTROSERVICIOS SEBA,C.B**, CL ISAAC ALBENIZ 4 BJOS , 30009 MURCIA , 968/ 29.85.93 / **VISATEL**, CL TORRE ALVAREZ S/N , 30007 MURCIA , 968/24.16.47 / **ELECTRO SERVICIOS PLAZA**, CL SIERRA DE PEÑARRUBIA 7 , 30009 MURCIA , 968/ 29.25.23 / **ANGEL LOPEZ ALCARAZ**, CL SIERRA DEL ESPARTAL 6 (EDIF. ANA) , 30009 MURCIA , 968/ 29.39.10 / **RAFAEL GOMEZ YELO**, PS CORBERA 17 , 30002 MURCIA , 968/ 26.14.67 / **LA SEDA REPARACIONES**, CL LA SEDA EDIF. LAS TERRAZAS ESC. 3 , 30800 LORCA , 968/ 47.18.79 / **ELECTRO SERVICIOS PLAZA**, CL MONSEÑOR ESPINOSA 3, 03300 ORIHUELA, 96/ 674.18.67

NAVARRA: UNITEC, CL FUENTE CANONIGOS 5, 31005 TUDELA, 948/ 82.74.34 / **ELECTRO REPARACIONES 2000**, CL MONASTERIO FITERO 26, 31011 PAMPLONA, 948/ 26.79.12

ORENSE: FERNANDEZ GONZALEZ JOSE, AV BUENOS AIRES 75 BJOS , 32004 ORENSE, 988/ 23.48.53 / **ANTONIO RODRIGUEZ ALVAREZ**, CL CABEZA DE MANZANEDA 7, 32005 ORENSE, 988/ 22.40.98

PALENCIA: ELECTRONICA JAVIER, AV CASTILLA 77 , 34005 PALENCIA , 979/ 75.03.74

PONTEVEDRA: CENTRAL DE SERVICIOS, CL ASTURIAS 10 BJOS. , 36206 VIGO , 986/ 37.47.45 / **IMASON**, CL LOUREIRO CRESPO 43 , 36004 PONTEVEDRA , 986/ 84.16.36 / **SIAL-ALVIMO S.L.**, C/ C.TORRECEDEIRA 92 BJOS. , 36202 VIGO , 986/ 29.93.01 / **ELECTRONICA CAMBADOS**, CL CAMILO JOSE CELA 13 , 36600 VILAGARCIA AROUSA , 986/ 50.83.27

SALAMANCA: J. DANIEL MARTINEZ, CL ABRAHAM LACUT 11-15 , 37003 SALAMANCA , 923/ 19.16.10

SEGOVIA: GUIJO S.T., CL TEOFILO AYUSO 2 LOCAL, 40002 SEGOVIA, 921/ 42.94.18

SEVILLA: ELECTRONICA TRIANA, CL EVANGELISTA 69-71 L-25 , 41010 SEVILLA , 95/ 433.83.03 / **LUIS RIVAS CALDAS**, CL FEBO 16 , 41010 SEVILLA , 95/ 451.73.55 / **INTERSAT SEVILLA**, CL BEETHOVEN 5 , 41008 SEVILLA , 95/ 443.02.26 / **ELECTRONICA BERSABE**, PASAJE MERINOS 62 A , 41400 ECIJA , 95/ 483.33.93 / **ELECTRO 93 S.L.**, CL MELLIZA 1, 41700 DOS HERMANAS, 95/ 472.37.16 / **ELECTRONICA GUILLEN**, CL LA CILLA 70, 41640 OSUNA , 954/ 81.12.96 / **JOAQUIN VILLASANTE GARCIA**, CL PABLO NERUDA 5, 41927 MAIRENA DEL ALJARAFE, 95/ 417.06.24 / **SERYVEN CANTILLANA**, CL JUAN XXIII 60, 41320 CANTILLANA , 95/ 573.11.69 / **ELECTRO 93**, CL P. IGLESIAS B-4, CONJ. 1, L-7, 41008 SEVILLA, 954/ 42.01.43 / **SONOMAT**, CL JUAN CURIEL 22 , 41005 SEVILLA , 954/ 58.10.66

SORIA: MEMQUESI S.L., CL REYES CATOLICOS 1, 42110 OLVEGA, 976/ 64.58.54 / **TECO**, CL ANTOLIN DE SORIA 10 , 42003 SORIA , 975/ 22.61.25

TARRAGONA: EURO TECNICS, CL MONESTIR DE POBLET 4, 43205 REUS, 977/ 32.24.89 / **ELECTRONICA S. TORRES**, CL ERNEST VILCHES 4-B L-2, 43005 TARRAGONA , 977/ 21.21.48 / **TECNO SERVEIS MORA**, CL PAU PICASSO 1, 43740 MORA D'EBRE , 977/ 40.08.83 / **SELECCO S.L.** , CL CALDERON DE LA BARCA 11 , 43870 AMPOSTA , 977/ 70.00.12 / **SERTECS, S.C.**, CL CAPUTXINS 22 BJOS. , 43001TARRAGONA , 977/ 22.18.51 / **ELECTRO SERVEI C.B.**, PS MOREIRA 10 , 43500 TORTOSA , 977/ 51.04.42 / **MAÑE GRIFOLLS**, CL JESUS 21 , 43820 CALAFELL , 977/ 69.04.39

TERUEL: TELESERVICIO BAJO ARAGON, CL ROMUALDO SOLER 4 , 44600 ALCAÑIZ , 978/ 87.08.10 / **ALEJANDRO HERNANDEZ**, CR ALCAÑIZ 1 BJOS. , 44003 TERUEL , 978/ 60.85.51

TOLEDO: ELECTRONICA RIVAS, CL BARRIO SAN JUAN 1 , 45600 TALAVERA LA REINA , 925/ 80.55.46 / **ELECTRONICA FE-CAR, S.L.** , AV SANTA BARBARA 30, 45006 TOLEDO, 925/ 21.21.45 / **ELECTRONICA JOPAL S.L.**, AV PURISIMA CONCEPCION 31, 45006 TOLEDO , 925/ 25.04.42 / **ELECTRO ANAYA**, CL VERTEDERA ALTA 14 , 45700 CONSUEGRA , 925/ 48.09.81

VALENCIA: SERVICIOS ELECTRONICOS, CL DOCTOR OLORIZ 3 , 46009 VALENCIA , 96/ 340.20.34 / **TECNO HOGAR**, CL DOS DE MAYO 41, 46700 GANDIA, 96/ 286.53.35 / **ALBERTO GORIAN ZANETTI**, CL MARQUES DE CACERES 58 , 46183 L' ELIANA, 96/ 274.17.47 / **VIDEOSERVITE**, PZ DE LA SAFOR 2 (B DCHA), 46014 VALENCIA, 96/ 377.90.90 / **TECNITOT REPARACIONS**, CL PRIMER DE MAIG 51, 46700 GANDIA, 96/ 286.04.69

VALLADOLID: ASIST. TECNICA MARCOS, CL PIO DEL RIO HORTEGA 2-4 , 47014 VALLADOLID , 983/ 29.78.66 / **ELECTRONICA VITELSON** , PZ DEL MERCADO 9 , 47400 MEDINA DEL CAMPO , 983/ 80.43.56 / **TEODORO NEGRO HERNANDEZ**, GLORIETA DESCUBRIMIENTO 4, 47005 VALLADOLID, 983/ 39.17.81

VIZCAYA: SERVITELE, CL AUTONOMIA 24 Galerias , 48012 BILBAO , 94/ 444.89.02 / **NEGREDO MARTIN DANIEL**, CL PADRE PERNET 8 , 48004 BILBAO, 94/ 411.22.82 / **COLLANTES MARTIN ONOFRE**, CL ORTUÑO DE ALANGO 7, 48920 PORTUGALETE, 94/ 483.21.22 / **TELNOR**, PZ JUANENE 5 TRAS. , 48950 ERANDIO , 94/ 417.04.97

ZAMORA: R.T.V. BLANCO, CL EDUARDO JULIAN PEREZ 9, 49018 ZAMORA , 980/ 51.14.41

ZARAGOZA: AGUSTIN RENALES SOLER, CL SAN ADRIAN SASABE 56 , 50002 ZARAGOZA , 976/ 59.01.28 / **ARAGON TELEVIDEO, S.C.**, CL BATALLA CLAVIJO 18, 50010 ZARAGOZA, 976/ 32.97.12

SWITZERLAND - http://www.sharp.ch
Sharp Electronics (Schweiz) AG, Moosstrasse 2, CH-8803 Rüschlikon, +41 1 846 61 11

SWEDEN - http://www.sharp.se Helpdesk 013-353900
Bild&Ljudservice, Roxviksgatan 8, 582 73 Linköping, 013-356250 **Tomi Elektronik**, Svandammsplan 2, 126 47 Hägersten, 08-186170 / **Tv Trim**, St Pauligatan 37, 416 90 Göteborg, 031-847200

NORWAY
Service Eksperten, Trondheimsvn 436B, N-0962 Oslo, 22 90 19 30

ICELAND
Braedurnir Ormsson Ltd, PO box 8790, IS-128 Reykjavik, +354-5332800 / **Hjolmtaekni Ehf**, Skeifar, IS-108 Reykjavik, +354-5332150

DENMARK
Elektronik Centret, Literbuen 10A, DK2740 Skovlunde, 44 50 30 00

SUOMI
Theho Video Oy, Niittyläntie 3, SF-0620 Helsinki, +35-891461500

R-879_[EN] spec+BackCov.qxd 5/29/07 3:29 PM Page 13

SPECIFICATIONS

AC Line Voltage		: 230 V, 50 Hz, single phase
Distribution line fuse/circuit breaker		: Minimum 16 A
AC Power required:	Microwave	: 1,45 kW
	Top Grill	: 1,25 kW
	Bottom Grill	: 0,65 kW
	Top Grill/Microwave	: 2,65 kW
	Bottom Grill/Microwave	: 2,05 kW
	Top and Bottom Grill	: 1,85 kW
	Triple	: 3,40 kW
	Convection	: 1,86 kW
	Convection/Microwave	: 2,06 kW
Output power:	Microwave	: 900 W (IEC 60705)
	Top Grill	: 1,2 kW
	Bottom Grill	: 0,6 kW
	Convection	: 1,8 kW
Microwave Frequency		: 2450 MHz * (Group 2/Class B)
Outside Dimensions		: 520 mm (W) x 309 mm (H) x 486 mm (D) **
Cavity Dimensions		: 343 mm (W) x 209 mm (H) x 357 mm (D) ***
Oven Capacity		: 26 litres ***
Turntable		: ø325 mm, metal
Weight		: approx. 19 kg
Oven lamp		: 25 W/240 - 250 V

* This Product fulfils the requirement of the European standard EN55011.
In conformity with this standard, this product is classified as group 2 class B equipment.
Group 2 means that the equipment intentionally generates radio-frequency energy in the form of electromagnetic radiation for heating treatment of food.
Class B equipment means that the equipment is suitable to be used in domestic establishments.

** The depth does not include the door opening handle.

*** Internal capacity is calculated by measuring maximum width, depth and height.
Actual capacity for holding food is less.

CE

As part of a policy of continuous improvement, we reserve the right to alter design and specifications without notice.

R-879_[EN] spec+BackCov.qxd 5/2/08 5:57 PM Page 14

SHARP

SHARP ELECTRONICS (Europe) GmbH
Sonninstraße 3, D-20097 Hamburg

TINS-A743WRRZ-H82

Gedruckt in Thailand
Imprimé au Thaïlande
Gedrukt in Thailand
Stampato in Tailandia
Impreso en Tailandia
Impresso em Tailândia